

manual’s dimension：315*140mm



Wireless USB Headset

USER GUIDE



www.truvoiceheadsets.com

Pairing with Devices:

OPTION 1 (Headset and USB Dongle Required) – Use any of the 2 guides below if your PC does not have built in Bluetooth.

Computer Only

1. Plug the Bluetooth dongle into an available port on your computer / softphone
2. Turn on BT50/60 (Button can be found at the bottom of the Earpiece)
3. Headset will connect to PC / Softphone (please allow up to 30 seconds)

Cell Phone and Computer

1. Turn on Bluetooth on Cell Phone
2. Turn on BT50/60 (Button can be found at the bottom of the Earpiece)
3. Once your Cell Phone finds the BT50/60 press connect and pair (it can take up to 20 seconds for the Cell Phone to locate the headset)
4. Once Paired turn the Bluetooth off on Cell Phone
5. Plug the Bluetooth dongle into an available port on your computer / softphone
6. Headset will connect to PC / Softphone (please allow up to 30 seconds)
7. Switch the Bluetooth back on the Cell phone and connect to BT50/BT60
8. Once Connected to the Cell Phone the headset will now work with both devices

OPTION 2 (Headset Only Required) – Use any of the 2 guides below if your PC Includes built in Bluetooth.

Connecting to a Single Bluetooth Enabled Device (Cell Phone or PC)

1. Turn on Bluetooth on Device
2. Turn on BT50/60 (Button can be found at the bottom of the Ear Piece)
3. Go into the Bluetooth settings and scan for new Bluetooth Devices (it can take up to 20 seconds for the Device to locate the headset)
4. Once Located please connect to the BT50/60

Connecting to Bluetooth Enabled Device (Cell Phone or PC)

1. Turn on Bluetooth on Device you are connecting to first
2. Turn on BT50/60 (Button can be found at the bottom of the Ear Piece)
3. Go into the Bluetooth settings and scan for new Bluetooth Devices (it can take up to 20 seconds for the Device to locate the headset)

4. Once Located please connect to the BT50/60
5. Turn Bluetooth off on the device you just connected to
6. Turn on Bluetooth on Device you are connecting to Second
7. Locate BT50/60 in Bluetooth Settings on your second device and connect
8. Go back to the first device and turn Bluetooth back on. Once this is turned on reconnect to BT50/60

You are now paired to both Bluetooth devices



PLEASE NOTE : If you have tried the above instructions and cannot get the headset to connect please make sure you unpair the BT50/60 headset from all devices, turn the headset off and remove the Bluetooth dongle from the computer and start the setup instructions again.

Prompt Tone Introduction

Headset Status	Tone
Power on	Power on
Power off	Power off
Pairing Successfully	Connected
Volume up/down	"toot"
Battery Low	"toot" every 5 minutes
Mic Mute	"toot" every 3 seconds

Headset LED Indicators

Headset Status	LED Status
Pairing Mode	Light flashes blue and red alternately
Pairing Successfully	Light flashes blue repeatedly every 5 seconds
Battery Low	Light flashes red rapidly
Charging Mode	Red light continuously on
Fully Charged	Blue light continuously on
Audio Status	Blue light in the state of breathing, and the red light off
Call (Busy) Status	Red light in the state of breathing, and the blue light off



Button Function

Button	Function	Action
On/Off Button	Headset on	Slide switch to icon "ON"
	Headset off	Slide switch to icon "OFF"
Plus Button	Volume up	Tap the Plus button to increase the speaker volume
	Next song	Long press the Plus button to switch to next song when playing music
Mic Mute	Mic mute	Press the mute button to activate mic mute during a call, there will be "toot" every 3 seconds while mute, repress the mute button to cancel mic mute
	Volume down	Tap the Minus button to decrease the speaker volume
Minus Button	Last song	Long press the Minus button to switch to last song when playing music
	Pause	Tap the Multi-function button when playing music
Multi-function Button	Answer/end call	Tap the Multi-function button
	Reject call	Long press the Multi-function button for 2 seconds

Pairing Name: TruVoice BT50/ TruVoice BT60
Bluetooth Specification: CSR-V5.0, dual mode, downward compatible
Frequency Range: 2.4GHz-2.480GHz
Support Protocols: A2DP, AVRCP, HFP, AAC, etc
Two Bluetooth devices can be connected at the same time
Transmission Distance: up to 30 meters (Transmission distance depends on the environment and Bluetooth device)
Maximum Talk Time: 20 hours
Standby Time: 200 hours
Working Temperature: 0 C° to 45 C°

Speaker:

Frequency: 20Hz-20KHz, Hi-Fi

Distortion: ≤1%

Sound Channel:

Binaural: Stereo

Monaural: Mono

Microphone:

Microphone: Directional noise reduction microphone

Acoustic Noise Canceling Structure

Crystal clear sound and voice (DSP)

Headset Battery:

Type: Lithium-ion polymer

Battery Capacity: 320mAh

Charging Voltage: 5V DC

Life Time: Minimum recharging 1000 times

Operating Temperature: -10 C° to +60 C°

Charging Time: 2 hours

Charging Interface: Micro USB

Charging Base:

Net Weight: 115g

Headset Net Weight:

TruVoice BT50 70g

TruVoice BT60 95g

Cautions

1. Most Cell Phones have headset power on screen display. When Headset battery is low, the headset will beep once in 5 minutes and the indicator will turn red. Please charge it in time.
2. Do not connect the full-charged headset to the charging circuit for a long time. Overcharging will shorten battery life.
3. Please keep the headset battery safe. Do not put the battery or the headset into fire or water to avoid explosion.
4. Do not use headset with high volume for extra long time, which may cause hearing loss. Always listen at a moderate level.
5. Don't charge with high voltage device, which may cause damage to the headset.
6. Make sure that the headset is fully charged before using it if unused for a long time.
7. Lifetime of the battery will be significantly reduced if your device is left uncharged for a long time. We therefore recommend that you recharge your device at least once a year.