

## **RF Wireless Touching LED Remote Controller**

**(Brightness Adjusting)**

**Model No.: FUT021**

### **1. Function of keys**


Key 1: ON

Key 2: OFF

Key 3: Highest brightness

Key 4: Medium brightness

Key 5: Lowest brightness



### **2. How to use**

1. Use your finger to touch the color ring, you can change the brightness from the highest to the lowest (100%-1%).

2. Resume function. The previous settings will be resumed while power on again.

3. Link / Unlink

Link: Press "Key 3" one time within 3 seconds when power on, the link is done when the light blinks 3 times.

Unlink: Press "Key 3" five times quickly within 3 seconds when power on, the unlink is done when the light blinks 6 times.

### **3. Caution**

Please don't touch or press the color ring while loading the batteries to protect the sensitiveness. Please use the remote controller 3 seconds after the batteries are loaded. Please reload the batteries when you find the color ring is not sensitive.