



Manually

① Play/Pause:
Double tap left/right earbud

Sound prompt

① Please avoid heavy drop or bump

Q: The earbuds volume cannot be adjusted

A: ① Long press the left earbud for 1.5s to decrease volume, long press right earbud for 1.5s to increase volume.
② When you adjust the volume, most Android phone won't display the change, you need to feel the volume change yourself(There's 15 grades volume in total)

Q: How to connect earbuds with device?

③The free service provided by this warranty does not include product accessories and other packaging, gifts products and so on.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

