


ANKER



Anker PowerConf
User Manual

At a Glance




- 1 Multi-function button
- 2 Volume down button
- 3 Mute button
- 4 Phone call button
- 5 Volume up button
- 6 Status LED
- 7 Power LED

- 8 Power button
- 9 Bluetooth button
- 10 Bluetooth LED
- 11 USB port (Type-A) for charge out
- 12 Audio output port
- 13 USB port (Type-C) for charge in


Connecting




a) Connect to your computer by using a USB cable.



b) Connect to your computer or mobile device via Bluetooth pairing.

Power on this product for the first time, it will automatically enter the Bluetooth pairing mode.




	Press	Enter Bluetooth pairing mode
	Flashes blue	Bluetooth pairing
	Steady blue	Bluetooth connected





- Each time you power on the product, it will automatically connect with the last successfully connected device if available.
- To disconnect Bluetooth, press the Bluetooth button again.

Powering On/Off

Press and hold the power button for 2 seconds to power on. The status LED will light on clockwise and then fade out. To power off, press and hold the power button for 2 seconds.







Power LED behavior

	Steady white	Power on
	Light off	Power off



- Once connected to your computer, it will automatically power on.
- It will automatically power off after 30 minutes of inactivity or no source.

Button Controls


	Press or press and hold	Volume up / down
	Press	Answer / End a call
	Press and hold for 2 seconds	Reject a call
	Press	Mute or restore the microphone
	Press	Play / Pause music

Status LED behaviors

Lights up white for 2 seconds	USB connected to computer
Breathes green	Coming call
Lights up blue partly	Sound direction detected
Lights up blue clockwise or counterclockwise	Increase or decrease volume
Turns red	Muted
Lights up green	Press Power button to check the battery level

Charging


a) Charging this product



Power LED behavior

Steady red	Being charged
Steady white	Fully charged
Flashes red	Low battery


b) Charging an external device



- When powered off or being charged, it won't charge out.
- When the remaining battery is less than 30%, the charge out current will be 5V $\overline{\text{---}}$ 1A; if less than 10%, it won't charge out.


Audio Output

Connect an external speaker to the AUX jack of this product by using an AUX cable (not provided). The audio will be played through the speaker.



Soundcore App

Download the Soundcore app for the software updates.



Google Play and the Google Play logo are trademarks of Google Inc.



Apple and the Apple logo are trademarks of Apple Inc.