

TWS function:

Two same model speakers can connect to make a TWS pair. Press and hold the TWS button for 3 ~ 4 seconds, after hearing a prompt and seeing an indicator light the speakers will be paired. Primary speaker will be left channel audio and secondary speaker will be right channel. Both speakers can control the functions and unpairing but only the primary speaker can re-pair.