

DAS.4

SG48

| User Manual



Operation Instructions

Upper button: On standby press the button to turn ON the screen. Press again to return to standby.

Down button: On standby press the button to turn ON the screen. Short press to enter sports mode. Long press for 10 seconds to restart the watch.

Screen gestures: Swipe right for SMS notifications, swipe left for the menu, slide down for the shortcut bar and swipe up to enter the functions.

Dial switch: Long press the main screen to enter the list. Browse left and right to choose a new dial.

Connection

Download and install the application "FunDo". You can scan the QR code below to download the App or you can search for the term "FunDo" on Google Play (Android)/App Store(iOS).

After installation, turn on Bluetooth and GPS on your smartphone. Open the FunDo App and accept all the essential permissions requested. Tap "More" at right bottom corner -> Add Device -> Find the device "W 3Pro" and tap to connect. The smartwatch will be successfully bound. Next go to Bluetooth settings on your phone and search for W3 Pro. Press to bind it with your phone so you can make and receive calls on your watch via Bluetooth.

Main Functions

Dial: Make a call via Bluetooth

Phonebook: Sync contacts from your smartphone

Call logs: Sync your call history from your smartphone

SMS: Sync all your messages (Doesn't support iOS yet)

Notification: Sends your smartphone notifications to your watch

Sleep: Monitor your quality of sleep from 9:00 p.m. to 9:00 a.m.

Heart Rate: Measure your heart rate

ECG: Electrocardiogram

Blood pressure: Measure your blood pressure

Blood oxygen: Measure your blood oxygen

Pedometer: Measure your steps

Remote Camera: Control your smartphone camera from a distance

Anti-Lost: Reminder when your smartphone is out of range

Multi-Language: Select your language

Calendar: See current day and month

Calculator: Make simple calculations

Stopwatch: Measure time

Alarm Clock: Set up an alarm

QR Code: Scan the code to download the App

Sedentary: Reminder to move

Gesture: Flip your watch to mute, Shake the device to answer a call

Restore Factory Settings: Restore devices default settings

About: Information about your device (MAC Address, Bluetooth Name)

Disclaimer

- 1) Please ensure that Bluetooth and mobile GPS are turned on. When searching for the device via Bluetooth, make sure that no other device is connected. When searching for the device via Bluetooth, keep a close distance between your mobile and smartwatch.
- 2) If the Bluetooth connection is unstable during operation, try restarting the watch and connecting it to the mobile again. Be sure to turn on the automatic start for the smartwatch application, in the settings of your mobile phone. Also turn off the battery optimization (without restrictions) for the specific application, so that the continuous application-smartwatch communication is not interrupted.
- 3) If there is a problem with the watch or its use, please contact the store where you purchased it.
- 4) The measurements of the watch are for reference only and not for medical use. Please follow your doctor's instructions and do not use the measurements to make your own diagnosis.
- 5) The watch is waterproof with IP67 certification which means that it can withstand accidental contact with water. However, it cannot be used for diving or being under water for a long time. In

addition, the watch should not come in contact with hot water, as steam can penetrate the seal and cause internal damage.

6) The company has the right to modify the contents of this user manual without prior notice. Some functions differ depending on the software they carry.

7) CAUTION: Do not use a power adapter that gives more than 5v == 1A to charge the device. If you use a charger larger than 1A for charging, the circuit and / or battery may be damaged.

8) Once the watch is charging, disconnect the cable from the power supply to prevent a short circuit if it comes in contact with conducting objects.

9) Do not leave the peripherals and accessories in areas where the temperature is too high or too low. Otherwise, the device may malfunction.

10) Avoid hitting the device to reduce the risk of damage.

The warranty terms that cover the product are mentioned in details on the official website www.das-4.com.

**IP67: Dust resistant!
Seawater is prohibited.**

www.das-4.com