


C-line Wireless Speaker

User Manual



1. Speaker

2. ON/OFF button

Bluetooth pairing for music

1. a. Turn on the speaker by pressing "S" button for 3 seconds. The speaker will have a voice prompt.
b. Stereo mode (only for two speakers):
Power on two C-line Speaker. Double press "S" on one C-line Speaker. Connected prompts are heard once the speakers are paired successfully. After the first pairing, the C-line Speaker will connect automatically when you turn them both on.
2. Turn on your device and activate the Bluetooth function.
3. Search for Bluetooth pairing name "C-line Speaker" and click to pair, the speaker will pair automatically and the speaker will have a voice prompt.
Then, you can play music or just need to press "S" button to pause the music.
4. Long press "S" button to turn off the speaker.

Specifications

Power Rating	5W
Frequency Response	20HZ-20KHZ
THD	<1%
S/N	>80DB
Speaker Parameter	4Ω 5W diameter 40mm
Input	12V DC
Bluetooth Version	Bluetooth V5.0
Product Size	Ø55 x 47mm
Product Weight	62g