

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. Any other trademarks are for reference purposes.

For regulatory compliance information including the EU Declaration of Conformity, visit www.arlo.com/about/regulatory/.



Arlo Technologies Intl. Ltd
Ground Floor, Building 3
University Technology Centre
Curraheen Road, Cork T12 EF21 Ireland

Arlo Technologies UK Limited
100 New Bridge Street
London, EC4V 6JA

Arlo Technologies, Inc.
2200 Faraday Avenue, Suite 150
Carlsbad, CA 92008 USA



September 2023



201-50703-10

Quick Start Guide

Essential Indoor Camera

2nd Generation

Get Started

To power on your camera, connect the USB-C cable to the included power adapter and plug in to an indoor power outlet.


- 1 Download the Arlo Secure App:




Or go to arlo.com/app/secure/

- 2 To start setup, tap **Devices** and then **+**, and select **Cameras > Essential Series > Essential Cameras 2nd Generation** and follow the prompts.

What's in the box




Arlo Essential Indoor
Camera & Stand



Wall Mount




Screw Kit



Power Adapter

Get to know your camera



Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and:

- How-to videos
- Troubleshooting tips
- Additional support resources

arlo

Guide de démarrage rapide

Essential Indoor Camera

2^e génération

Pour commencer

Pour allumer votre caméra, branchez le câble USB-C sur l'adaptateur secteur fourni, puis branchez-le sur une prise intérieure.


1 Téléchargez l'application Arlo Secure:




Ou visitez le site
arlo.com/app/secure/

2 Pour commencer la configuration, appuyez sur **Devices** (appareils), puis sur , et sélectionnez **Cameras** (caméras) > **Essential Series (Série Essential)** > **Essential Cameras 2nd Generation** et suivez les instructions.

Contenu de l'emballage




Arlo Essential Indoor Camera
et support



Montage
mural




Ensemble
de vis



Adaptateur
secteur

Découvrez votre caméra



Besoin d'aide?

Nous sommes là pour vous.

Visitez www.arlo.com/support pour des réponses rapides et:

- Vidéos de démonstration
- Conseils de dépannage
- Ressources d'assistance supplémentaires

arlo

Guía de inicio rápido

Essential Indoor Camera
(segunda generación)

Comenzar

Para encender la cámara, conecte el cable USB-C al adaptador de alimentación incluido y conéctelo a una fuente de alimentación para interiores.


- 1 Descargue la aplicación Arlo Secure:




O visite arlo.com/app/secure/

- 2 Para iniciar la configuración, presione **Dispositivos** y, a continuación **+**, seleccione **Cámaras > Serie Essential > Essential Cameras 2nd Generation** y siga las indicaciones.

Contenido




Arlo Essential Indoor
Camera y soporte



Montaje en
pared




Kit de
tornillos



Fuente de
alimentación

Conozca su cámara



¿Necesita ayuda?

Estamos disponibles para asistirlo.

Visite www.arlo.com/support para obtener respuestas rápidas y los siguientes elementos:

- Videos instructivos
- Consejos para solucionar problemas
- Recursos de soporte adicionales