



Hello!

Model: LTW-S35 True Wireless Sport Earbuds User Manual

Please fully read this Manual before using this Product for the very first time and well keep it for further reference.



Dear Customer

Thank you for choosing LinkTech's products, we appreciate your choice to purchase this product and we're hoping that you'll have a great time using our product.

Please share your experience with our products through LinkTech's customer services center either by phone, Whatsapp or Bip.

Feel free to express your opinions or tell us your suggestions on our channels. LinkTech will happily review all your invaluable feedback in order to improve our products and services.

If you encounter any problem or have difficulties with this product, please refer to the User's Manual, you can contact our customer services if you have any further questions.

LinkTech considers your priceless recognition and support as an encouragement to stay focused on providing high quality products and a motivation to move forward, improve our services and expand our workspace in the future.

LinkTech's Sales Team

SPORT BUDS IX




ENC | 4 Microphones
for clearer calls

User's Manual

We recommend using the cable that was included in the package to charge the earphones.

Contents List



TWS Earbuds
(2 PCS)



Charging Case
(1 PCS)



User's Manual
/Warranty Card (1PCS)



USB-A to USB Type-C
Charging Cable (1PCS)

Product Characteristics and Features

- **Bone Conduction Technology:** Experience immersive audio as sound is delivered through vibrations to your cheekbones, keeping your ears open to the environment.
- **Bluetooth v5.4 Stable Connection:** Enjoy a seamless, low-latency connection with Bluetooth 5.4, perfect for gaming and video streaming.
- **Directional Sound Transmission:** Privacy-focused directional sound ensures that your conversations stay discreet and within your ear range.
- **Ergonomic Ear Hooks:** Secure, ergonomic ear hooks stay in place even during vigorous outdoor activities.
- **Open-Ear Comfort:** Weighing only 8.9g, the open-ear design ensures lasting comfort without pressure on the ear canal or risk of falling out.
- **A robust charging case with futuristic design, 400mAh battery and USB Type-C charging port.**
- **Large 14.2mm dynamic drivers** optimized to deliver a natural sound
- **Smart touch controls,** to control your music and calls with a tap of a finger.
- **Game Mode Support,** allows you to have lower latency for smoother experience
- **IPX5 water resistance**

Product Specifications

Bluetooth Version	V5.4
Bluetooth Range	>10 Meters
Impedance	160Ω±15%
Speaker Driver	14.2mm Dynamic Speaker
Waterproof Rating	IPX5
Frequency	20Hz~20KHz
Charging Port	Type-C 5V--320mA
Working Temperature	-15°C~50°C
Charging case weight	61g
Case charging time	Up to 1.5 hours
Charging case battery	400mAh-3.7V
Total playtime with charging case	Up to 13 hours
Earbud battery	50mAh-3.7V
Earbud weight	9.3g (each)
Earbud charging time	1.5 hour
Working voltage	3.1V-4.2V
Standby time	About 90 Hours
Playtime	5.5 hours at 70% volume

Safe Use Information

Read the instructions carefully before use, appearance and specifications of the device may be resized and different from the image in this manual without prior notice.

-  Do not listen to music at maximum volume for long periods of time as this can damage your hearing.

Safe Use Information

- ⚠ Consult a physician regarding the use of this device with medical equipment, or consult a medical device manufacturer for this matter
- ⚠ Use only certified wall chargers.

Do not do the following with the device and battery


- Do not disassemble it on your own
 - Do not repair it on your own
 - Do not try to modify it
 - Do not overheat the battery
 - Do not expose it to direct sunlight
 - DO not immerse it in water
 - Keep it away from sources of fire or open flame
 - Do not expose this product to very low or very high temperatures, below 0°C or above 45°C
 - Contact an authorized service technician.
-
- ⚠ Do not use this product during a thunderstorm, there is a risk of electric shock or device malfunction.
 - ⚠ The metal contacts of the headphones and charging case must be free of dirt and not covered by foreign objects.
 - ⚠ Do not use this device in places with strong exposure to an electromagnetic field, this can lead to incorrect operation or damage the device.

Quick Start Guide


1. Before using the device, remove the earbuds from the case and remove the protective film from the charging contacts of the earbuds.
2. Fully charge the case along with the headphones, use the supplied cable (power adapter is not included).

Music play

- Play/Pause music: Double tap function button
- Previous song: Triple tap Left function button
- Next song: Triple tap Right function button
- Volume -: Single tap Left function button
- Volume +: Single tap Right function button



Reset button



Game/Music mode

- Press & hold Right function button 2 seconds

Calling Manage

- Taking/ hang up the calling: Double tap function button
- Reject calling: Press & hold function button 2 seconds

Voice Assistance

- Press & hold Left function button 2 seconds
(Need phone support this function)



Imalatçı Firma
LINK-TECH TRADING COMPANY LIMITED
FLAT 609A, 6/F. FOOK CHONG BUILDING 63 HOL YUEN
ROAD, KIWUN TONG, KOWLOON, HONG KONG
TEL: 3114 7567