



# Using pureAir FRIDGE

## 1. Turn pureAir FRIDGE on by pressing the ON/OFF Button once.

- The Indicator Light flashes Green to show pureAir FRIDGE is on.
- If the Indicator Light doesn't flash Green, charge pureAir FRIDGE (see below).

## 2. Place pureAir FRIDGE anywhere in your refrigerator.

- Take care not to put anything against the Top Air Vent or Rear Air Intake.

## 3. Turn pureAir FRIDGE off by pressing the ON/OFF Button again.

Note: The Indicator Light always flashes green whenever the refrigerator door is open and pureAir FRIDGE has enough charge. The Indicator Light turns off automatically whenever the refrigerator door is closed to preserve battery life, but pureAir FRIDGE is still working.

## Charging

Beeping and a Red Indicator Light tell you that pureAir FRIDGE needs charged. Connect a powered USB-C Cable to the Charging Port. pureAir FRIDGE is charged and ready when the Charging Port Light changes from Red to Green.

Initial charging time varies and can take up to eight hours, so you might simply let it charge overnight. After this first charge, it will only take four to six hours to charge. The charge will last about three weeks before needing to be charged again.