HAVIT



W3100
FOLDABLE 3 IN 1 WIRELESS CHARGER
USER MANUAL

Packing List



Foldable 3 in 1 Wireless Charger*1



USB-C to USB-C Cable*1



User Manual*1



Warranty Card*1

Product Structure



Specification

Product Model: W3100
Product Name: Foldable 3 in 1 wireless charger
Material: ABS+zinc alloy+aluminum alloy
Input: 5V = 3A, 9V = 3A
Wireless Output:
Phone: I5W (compatible with 10W, 7.5W and 5W)
iWatch: 3W (max)
Earbuds: 5W (max)
Size: 72.5*72.5*28mm
Weight: 160g±5g

Use Instructions:

- 1. Plug one end of the USB-C charging cable into this product and the other end into the power adapter, the product will enter normal working state.

 2. Indicator light status: After the power is turned on, the indicator light will light up blue immediately.

 3. Stand up the mobile phone charging stand, and the user can freely adjust the required angle.

 4. This product can wirelessly charge three devices at the same time: phone, earbuds, and watch.

Warning:

Please do not disassemble this product by yourself. Please do not place this product near heat sources. Please do not place this product close to water or in a humid place.



The distinct surprises with part to if the PCC Bales. Operation is subject to the foliating the conditional (1) this distinct is reserved, on the principle surprise of the principle surprises of the principle surprises. A principle surprises of the principle surpr

no securing attentia.

Increase the separation between the equipment and receiver.

Connect the equipment into an outet on a cleual different from that to which the receiver is connected.

Consult the dealer or an especienced radioTV storholden for help.

Consult the dealer or an experienced radioTV technician for help.
 FCR RF exposure statement.
 The equipment complies with FCC satisficion exposures limits set from first an uncontrolled environment. This equipment should be installed and operated with minimum distance between 25cm the radiator your body.



www.havitsmart.com

尺寸(Size): 55 X 77 mm

注: 1-3页(1-3画板)为正面 4-6页(4-6画板)为反面

风琴折 (从封面往封底方向像折扇子一般折叠)

