


# 10 INCHES HIGH POWER RING LIGHT WITH LIGHT STAND KIT

Instruction Manual


## Product Overview

- RH10B Ring Light is made of high-strength plastic for portability and durability.
- A brand new design that is lightweight, compact, yet powerful.
- Ideal for live streaming, vlogging, and use in the medical and cosmetic domains.
- The ring light comes with a light stand, phone mount, and ball head, and features a cold shoe for mounting additional accessories.

## Package Contents




Ring Light×1




Ball Head x 1



Power Adapter×1



1 x Phone Holder  
with Flexible Tube  
Arm



USB Type-C Cable×1



Bluetooth Remote (for  
Smartphone camera)×1




Manual×1



Light Stand×1

## Remote control



### ① ON/OFF Button:

Slide the side switch to power on or off.

### ② Screen:

LED Screen.

### ③ Mode Button:

Short press to choose CCT or FX mode.

### ④ Sub-Mode Button:

Short press to choose sub-modes in the current mode.


### ⑤ Values + Button:

Short press to choose scenes or increase values. Long press to increase quickly.


### ⑥ Values - Button:

Short press to choose scenes or decrease values. Long press to decrease quickly.

## Setting Up the Stand




1. Loosen the leg locking knob and spread the legs to a suitable angle, then re-tighten the knob to secure.




2. Mount Ball Head A on a tripod first.

Insert the 1/4" screw into the bottom thread of the ring light, then tighten the ball head.


## Installing the Phone Mount




- ① Cold Shoe Locking Ring
- ② Flexible Tube Arm
- ③ Phone Holder



1. Insert the base into the cold shoe mount on the ring light.




2. Rotate the cold shoe locking ring clockwise until it locks in place to secure the phone holder.




3. The phone holder can be manually expanded on both sides to accommodate different phone sizes..

## Power Supply

Plug the power adapter into a wall socket, then connect it to the remote control device with a USB Type C cable for power supply.



## Light Modes




### CCT Mode:

When power is on, press the "M" button to choose the CCT mode.

Short press the "SET" button to switch between CCT and INT sub-modes.

In the CCT sub-mode, short press "+/-" buttons to adjust.


## Light Modes



### INT Sub-Mode:

Short press the "SET" button to choose the INT sub-mode.

In the INT sub-mode, short press "+/-" buttons to adjust.




### SCENE Mode:

When power is on, press the "M" button to choose the SCENE mode.

Short press the "SET" button to switch between FX and INT sub-modes.

In the FX sub-mode, short press "+/-" buttons for scene selection.

## Light Modes



### INT Sub-Mode:

After selecting a scene, short press "SET" button to choose the INT sub-mode.

In the INT sub-mode, short press '+'/'-' buttons to adjust.

### List of Scenes:



Lightning



Paparazzi



Defective Bulb



Explosion



Welding



CCT Flash



CCT Pulse



Candlelight



CCT Loop



INT Loop




TV Screen




Fireworks

## Pairing with Bluetooth Remote



Turn on the remote, then go to the Bluetooth settings on your phone to discover and connect to the device name "NEEWER Shutter".



Open your phone's camera app and press the shutter release button to take photos.

**⚠ If the indicator doesn't light up, please check if the battery cover is loose or replace the battery**

## Caution

1. Avoid direct eye contact with the light to prevent vision damage.
2. Never attempt to disassemble or repair the product yourself as it may result in personal injury.
3. Always use the provided or certified power cables and power adapters.
4. Do not clean with alcohol or liquid.
5. Handle with care. Avoid hitting, colliding, and dropping the product.
6. Do not exposure to direct sunlight for long periods of time.
7. Unplug the power cable when not in use.
8. Clean with a soft, dry cloth.
9. Not adhering to the above will automatically invalidate the warranty.

## Specifications

Model	RH10B
CRI	≥97
TLCI	≥98
Number of LEDs (2900K)	84 pcs
Number of LEDs (7000K)	84 pcs
Color Temperature	2900K-7000K
Input	5V/2A, 9V/2A, 12V/2A
Power	24 W
Max Illuminance	1660 lx/0.5m
Special Effects Modes	12

If you have any questions about product, we are glad to help.




US +1 732-623-9777 / UK +44 (0) 3330113494



Send us an email [vip@neewer.com](mailto:vip@neewer.com)



[www.neewer.com](http://www.neewer.com)



Facebook



[www.neewer.com](http://www.neewer.com)



Tiktok

UK REP

Lingfeng Electronic (UK) Ltd  
International House, 10 Churchill Way, Cardiff,  
CF10 2HE, United Kingdom  
[office.lingfeng@gmail.com](mailto:office.lingfeng@gmail.com)  
(for both batteries and products)

EC REP

NW Formations GmbH  
Hoferstrasse 9B, 71636 Ludwigsburg, Germany  
[info.nwformations@gmail.com](mailto:info.nwformations@gmail.com)  
(for both batteries and products)

Shenzhen Neewer Technology Co.,Ltd.  
深圳市纽尔科技有限公司

Room 1903, Block A, Lu Shan Building No. 3023  
Chunfeng Rd Luo Hu District, Shenzhen  
Guangdong 518001, China  
[vip@neewer.com](mailto:vip@neewer.com)