

Model No: MH22230

MONSTER™

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Product Overview

Earphones x2 (L & R)

Charging case x1

USB-C cable x1

Quick start guide and Warning card

Charging

Before using the " Monster N-Lite 212 " , please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.

Power On/Off

Open the charging case cover and remove the earphones, which will automatically turn on. If you want to turn off the earphones, please put the earphones into the charging case and close the cover,the earphones will power off and charge at the same time.

Pairing

Open the charging case and remove the earphones, which will automatically turn on,For new device connection, turn on the

Bluetooth in your device and choose " Monster N-Lite 212 " from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device. If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

Wearing

Put the " Monster N-Lite 212 " onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.

MFB Operation

Answer call

End call

Reject call

LED indicator (earphone )

Power on

Power off

Pairing is successful

Pairing timed out

Disconnect the phone

Low battery

LED indicator (charging case)

Charging

Discharge

Press L or R twice

Press L or R twice

Press MFB on the left or right earphone for 2 seconds

White flashes

The red light on 2s and then turn off

The white light on 1s and then turn off

The red light on 2s and then turn off

White flashes

red light flashes slowly

The battery level digits on the digital display screen flash, and the battery level digits on the display screen will continuously increase during the charging process

When charging the earphones, the corresponding battery bar flashes from bottom to top, and the screen turns off when fully charged

Attention

\*Private replacement of batteries without permission is not recommended.  
\*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.  
\*The input voltage and current standard ≤ 5V/1A when charging the headset charging compartment from an external power source;

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and the receiver.  
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio / TV technician for help.  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received. Including interference that may cause undesired operation.  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.  
FCC ID: 2AVD2-MH22230

Model No: MH22230

MONSTER™

快速指南

请仔细阅读快速指南并妥善保存以备将来使用  
本产品由中国平安保险公司承保

产品概述

耳机x2 (左&右耳)

充电盒x1

USB-C充电线 x1

快速指南/合格证

充电

请在使用此设备前先给耳机和充电仓充满电,此设备可以通过USB-C接口进行充电。

电源开、关

打开充电盒盖,取出耳机,耳机将自动开机。如果想要关闭耳机,请将耳机放入充电盒,耳机会关机同时进行充电。

配对

打开充电盒,取出耳机,耳机将自动开机。对于新设备连接,请打开蓝牙设备并搜索“ Monster N-Lite 212” 进行连接,配对成功后,您会听到系统提示音。如果耳机之前已配对过,开机就会尝试连接上一次的设备。

佩戴

拿出耳机,将“ Monster N-Lite 212” 放入耳中,并轻轻旋转至舒适位置,以确保获得最佳的佩戴效果和音质体验。

按键操作

Answer call

End call

Reject call

LED 指示灯 (耳机)

开机

关机

配对成功

配对超时

断开手机连接

低电提醒

LED 指示灯 (充电盒)

充电

放电

双击左或右耳

双击左或右耳

长按左或右耳MFB键2秒

白灯快闪

红灯长亮2S熄灭

白灯长亮1S熄灭

红灯长亮2S熄灭

白灯快闪

红灯慢闪

数显屏电量个位数字闪烁,充电过程中显示屏电量数字会不断增加

仓给耳机充电时,对应的电量条从下往上跑马闪,充满后屏熄灭

更多操作

恢复出厂设置

开机状态下连续5击耳机触控键(双耳同时),耳机将自动关机。恢复出厂设置。耳机放入充电盒再取出,耳机重新开机,进入配对模式。

注意

\*不建议未经许可私下更换电池。  
\*电池[电池组或电池组合]不得暴露在照明,烘烤或类似过热的环境中。  
\*耳机充电仓在外接电源充电时,输入电压电流标准≤ 5V/1A;

封面

75X95MM 105G双胶+K+186C印刷+风琴折

