

Jabra Engage 65 Convertible


How do I manually reset my Jabra Engage 65 to the default settings?

When you reset your Jabra Engage 65, previous settings will be cleared.

To reset the headset using the base, follow these steps:

1. Dock the headset in the base.
2. Simultaneously press and hold (3 seconds) the **Answer call** button and the **End call** button on the base.

The headset and base will reboot and all settings will return to their default values.



Note

You can also reset the base and headset using Jabra Direct.

Images are for guidance purposes only. The displayed image may differ slightly from your device, however the content is still relevant and accurate.