




Instruction Manual




**Model No. OTSELFITE
SELFIE LIGHT**

Pack Contents


1. Selfie light
2. Instruction manual
3. Micro USB charging cable

Features



1. Power On/Off/Brightness Level Button
2. Charging Indicator
3. Micro USB Charging Port
4. Anti-slip Mat
5. Clip
6. LED Light Surface

Charging



1. Please charge your selfie light when:
 - a. Power button is pressed and the light does not turn on.
 - b. Light emitted noticeably decreases during use.

Charging Instructions:

- a. Connect the Micro USB end of charging cable to the charging port on selfie light.
- b. Connect the USB end of charging cable to a USB power adaptor.
- c. When charging, the charging indicator light will illuminate in red.

Once fully charged, the red led light will turn off.

Product Specifications

LED Quantity: 28 pieces


Max Power: About 3W

Charging Voltage: DC5V

Continuous Light: Approx. 45 minutes

Battery: 150mAh - 3.7V

Installation and Usage Instructions



1. Clip selfie light onto phone or smart device in a suitable position (ensuring it does not interfere with any phone buttons or cover the camera lens).
2. Press On/Off Button to turn on light.
3. Start recording or taking images.

4. The selfie light has 3 brightness levels. To switch between the brightness levels use the On/Off Button.
- a. Pressing this button once will turn on the selfie light to the first brightness level.
 - b. Pressing this button a second time will change the brightness to the second brightness level.
 - c. Pressing this button a third time will change the light to the third brightness level.
 - d. Pressing this button a fourth time will turn the selfie light off.

Compatible Devices

The selfie light is compatible with most smart phones and smart devices. The clip can be clipped onto a device up to 12mm in depth.

WARNING

Do not connect this cable to products other than OTSELFITE selfie light. Connecting this cable to other devices might cause damage to both cable and the device.

Warning

- Read manual carefully before using this product.
- Keep manual for future use of product.
- Ensure phone ring light is secured properly to device before using.
- Do not expose to water or use/store in a damp environment.
- Turn off when not in use.
- Clean by using a soft, dry cloth.
- Keep out of reach of children.
- If the product becomes damaged, do not continue use and seek a professional to repair.

Product Warranty – – valid for Australian customers only

Officeworks Ltd warrants that this product will be free from defects and work as intended for 3 years from the date of purchase by the original customer.

If the product has any defects or does not work as specified during the Warranty Period, Officeworks will, at its election and at its expense, repair or replace the product.

This warranty does not apply:

- to cosmetic damage;
- to damage caused by consumables used in connection with the product (such as batteries);
- where the product has not been used in accordance with all provided instructions;
- to damage arising from fair wear and tear;
- where the product has not been subject to reasonable use;
- where the product has been intentionally or negligently damaged; and/or
- if the customer has attempted to repair the product.

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

This warranty is provided in addition to any rights you may be entitled to under the Competition & Consumer Act 2010. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.