









XS4 Original+ SKG** models



The XS4 Original+ product line is a universally compatible advanced smart locking system delivering next-generation access control technology in a market-proven solution. Unique, simple to install and retrofit, and featuring a sleek design, the XS4 Original+ platform integrates all your physical security needs through wireless networked, stand-alone locks giving you real-time access control for virtually all the doors in your building.


E i 4xx.. S series






(Eng) Select handing (F) Choisir le sens de la bêteuille (E) Seleccione mano (NL) Hand selectie


1




2




3




4




5



6




7




(Eng) Installation (F) Installation (E) Instalación (NL) Montage


1




2




3




4




5




6




7




8



9



10



AT THIS POINT DO NOT
CLOSE THE DOOR
PROGRAM THE LOCK
FIRST

NE FERMEZ PAS LA PORTE.
PROGRAMMEZ LA BÉQUILLE
AVANT



NO CIERRE LA PUERTA.
PROGRAME LA CERRADURA

SLUIT DE DEUR NOG NIET!

TÜRE NICHT SCHLIESSEN!

(Eng) **Battery change** (F) **Remplacer les piles** (E) **Cambio de pilas**
 (NL) **Batterijwissel** (D) **Batterie tauchen**

LR03



E i 450.. S series

