

**(Fold Inward)** 

## Compliance Information

## Warranty Information

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

**⚠ Caution**

To ensure safe and proper use, read all safety information before using the product. Do not use the product with manufacturer-approved batteries, chargers, accessories, or supplies.

**THIS DEVICE IS NOT A TOY** do NOT allow children or pets to use or play with this device.

- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- Do not use with a USB adapter. Make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to come in contact with any liquid.
- Do not use with any other conductive materials such as liquids, metallic powders, etc.

The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

Diagram illustrating the location of controls on the back of the earcup:

- TYPE-C Port
- LED Indicator
- Mic
- 3.5 mm AUX Input
- Bottom of Earcup
- + / - / M / B Button: Next Track, Increase Volume
- Power On/Off, Play/Pause Media, Answer/End Calls
- [ M ] / [ B ] Button: Previous Track, Decrease Volume

### Charging the Headphones

Plug the small connector of the included charging cable into the TYPE-C charging port on the headphones. Plug the large connector into a USB power source such as the USB port on a computer, or a 5V USB adapter (not included) and plug into a wall socket.

The LED indicator will turn RED while charging and turn OFF when fully charged. On low power, a tone will be heard indicating that the headphones need to be recharged.

**Powering ON/OFF**  
Please charge the headphones fully before using.

- **Long-Press (3s)** the **(ON)** button to power the headphones ON. The LED indicator will flash BLUE.
- When powered ON, the headphones may automatically reconnect to the device most recently paired to, so long as that device is within connection range (33 ft.) and Bluetooth is enabled.
- **Long-Press (3s)** the **(ON)** button to power the headphones OFF. The LED indicator will turn OFF.

### In the Box

- TXULLEDBTHP - Wireless Headphones (x1)
- TYPE-C Charging Cable (x1)
- Instruction Manual (x1)

- Press the [0/7] button to PLAY/PAUSE playback.
- Press the [▶|←] button to skip to the PREVIOUS track.
- Press the [⏮|⏭] button to skip to the NEXT track.
- Long-Press the [▶|←] button to DECREASE the volume.
- Long-Press the [⏮|⏭] button to INCREASE the volume.