

INSTALLATION

Product Manual

Version: 510013-01-25A-HX

Important Safety Instructions



Warning! To reduce the risk of serious injury, read the following safety instructions before assembling and using the gazebo.

Please check with your local governing authority/local municipal codes regarding installation of structures before assembly.

Caution! Proper placement of your gazebo is essential.

Do not place the product underneath electrical lines.

Keep children away during assembly.

This product contains small parts which can be swallowed by children.

Keep fingers away from the places where they can be pinched or trapped.

Do not attempt to assemble the gazebo if any parts are missing.


- This product is intended for domestic outdoor use only.
- The product should be placed on flat, horizontal ground.
- Ensure enough clearance around the product. Before assembling the product, find level ground not less than 6' (1.8 m) away from any structures or obstructions, such as fences, garages, houses, overhanging branches, laundry lines, or electrical wires.
- This gazebo is not to be regarded as part of a building/house structure. The gazebo is to be anchored onto the ground for added safety. Do not assemble the gazebo onto soil/earth ground. It is best advisable to have the gazebo built onto a wooden deck or concrete ground for stability. If it is to be built onto a wooden deck/ground, do ensure that the wooden deck/ground has a strong foundation. It is advisable to use appropriate floor plugs (not provided) to anchor the gazebo onto the wooden/concrete ground.
- Some structures may require two or more people to install safely. Check for underground utilities before digging or driving stakes into the ground.
- During installation, follow all safety warnings provided with your tools, and use safety glasses.
- In case you set up more than one gazebo, keep a minimum distance of 10' (3 m) between the gazebos.
- Any assembly or maintenance of the product must be carried out by adults only.

- Arrange necessary manpower when assembling or moving the product.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- Keep children and pets away while setting up the gazebo.
- Check all nuts and bolts periodically to ensure bolts/nuts are tightened.
- Repairing and replacing parts should be done by a qualified technician.
- This gazebo is intended for decorative and sunshade purposes only, and it is not designed to withstand harsh weather, including high winds, rain, and snow.
- Do not light any fires inside or near the product!
- Stay calm if fire breaks out. Search for the nearest exit. Do not return to the gazebo before firemen allow you to do so.
- Do not hang heavy weights on the roof frame.
- Do not climb onto the roof of the gazebo. Falling off the gazebo can result in serious injury.
- Retain the original packaging to store the gazebo.


Pre-assembly

TOOLS THAT MAY BE REQUIRED (Not included in boxes)

*NOTE: Tools / equipment are not shown to actual size and scale.



LEVEL




RUBBER Mallet




PHILLIPS SCREW



DRILL



ALLEN KEY



ALLEN KEY

EQUIPMENT REQUIRED (Not included in boxes)

*NOTE: Equipment are not shown to actual size and scale.



SAFETY HAT



GLOVES



SAFETY GOGGLES



STEPLADDER


Matters needing attention






1. Two or more people are required for assembly.



2. Do not fully tighten screws prior to complete assembly.



Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

H1 x 17




M6 x 15 mm

H2 x 12



M6 x 50 mm

H3 x 50




M8 x 45 mm

H4 x 30




M4 x 25 mm

H5 x 8




M4 x 50 mm

H5 x 8




M4 x 50 mm

H6 x 4




M4 x 90 mm

H7 x 16




M6

H8 x 58




M9 x 18 mm

H9 x 12




HQ x 8




M8 x 70 mm

HW1 x 2




M4

HW2 x 2




M5


HW3 x 2




A1x1




A2x1




A3x1




A4x1




B1x1




B2x1




B3x1




B4x1




C x4




D x2




E x2




F x2




G1x2




G2x2




J1x2




J2 x2




J3 x2




K x2




L x4




M x8





P1 x3















P2 x2















1

H3 x 12  M8 x 45 mm	H5 x 2  M4 x 50 mm	H6 x 2  M4 x 90 mm	H8 x 16  M9 x 18 mm	HW2 x 1  M5	
(A1) x1 	(A2) x1 	(B1) x1 			
(C) x2 					








2

H3 x 12  M8 x 45 mm	H5 x 2  M4 x 50 mm	H6 x 2  M4 x 90 mm	H8 x 16  M9 x 18 mm	HW2 x 1  M5	
(A3) x1 	(A4) x1 	(B2) x1 			
(C) x2 	(B3) x1 	(B4) x1 			




3

H3 x 12  M8 x 45 mm	H8 x 12  M9 x 18 mm	HW2 x 1  M5	
(D) x2 			




4

H3 x 12




M8 x 45 mm

H8 x 12





M9 x 18 mm

HW2 x 1






M5

(E) x2




5

H5 x 4
M4 x 50 mm




6






H5 x 8
M4 x 50 mm








G1 x2





G2 x2



7

H2 x 12  M6 x 50 mm	H7 x 12  M6	H9 x 12 	HW1 x 1  M4	HW3 x 1 	
(P1) x 3 		(P2) x 2 			




8

H1 x 4
M6 x 15 mm


HW1 x 1
M4

J1 x 2



9

H4 x 8





M4 x 25 mm




(J2) x2




(J3) x2




10

H1 x 12  M6 x 15 mm	H4 x 4  M4 x 25 mm	H7 x 4  M6	HW1 x 1  M4	HW3 x 1 	
(K) x2 	(L) x4 				






11

H4 x 16






M4 x 25 mm

(M) x8



12



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT



adelahu@fufugaga.com



208-820-0068