



Original	Recharge
 Power	 Power
 [+]	 Picture / Format
 [i+]	 Info / Angle
 <</<I	 << / Tune-
 Play Bravia Sync	 Play / Slow
 Pause Bravia	 Pause / Step / Freeze
 >>/I>	 >> / Tune+
 Sync Menu Bravia Sync	 D.Menu / Top
 Stop Bravia Sync	 Stop / Hold
 Theatre Bravia	 TV/Radio /
 Digital	 Display / Media
 Analog	 Smart / List
 [...]	 Subtitle / EQ
 Audio	 Audio / Lang I/II
 Guide	 Guide / EPG / -/--
 Source	 AV / Input / RDS
 Return	 Back / Return

Original	Recharge
 Options	 Setup / OPT /
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 Home	 Menu / Home
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6



