


Wheel Pet Feeder AF050 WIFI Version




After-sales Service: Should any questions, please contact the 24-hour online customer service team directly.

Product Information

Product Model:	AF050
Product Material:	ABS
Capacity:	2.6L/0.69GAL (fit for dry food only)
Feeding Amount:	1-10 portions
Maximum meal output:	4 meals/day
Notice:	Please use 3 D-size batteries

Packing List



Pet Feeder Machine x1



Feeding Bowl x1




USB cable x1



AC power adapter x1

Control Panel



Indicator Light

Power Button

Green light: Device connection successful
Green fast flashing light: Without network
Red light: Without batteries
Red fast flashing light: Low battery power
Red & Green lights in turn and fast flashing: Device doesn't work

Long press 2 seconds: Turn on/off
Long press 5-8 seconds: Resetting
Single click: Feeding plan setting
Green slow flashing light: Waiting for connection

3 Meals Per Day Definition:
After confirming the number of meals and portions, the first meal is dispensed, and the timer starts. The three meals are evenly distributed over 24 hours, with one meal dispensed every 8 hours.

4 Meals Per Day Definition:
After confirming the number of meals and portions, the first meal is dispensed, and the timer starts. The four meals are evenly distributed over 24 hours, with one meal dispensed every 6 hours.

Long-press Operation

Power On/Off:
Press and hold for about 2 seconds to turn the device on/off. When powered on, the screen will light up and the device enters operational mode.

Factory Reset:
During operation: Press and hold for 5-8 seconds. The device will power off and restart automatically. Upon successful reset, the indicator light will pulse slowly (breathing effect). All meal schedules will be cleared and paired mobile devices will be unlinked.

When powered off: Press and hold for 8 seconds. The device will power on and perform reset. Successful reset is indicated by a slow-pulsing (breathing) light.

Maximum setting: 【10】 portions After reaching "4 meals/10 portions", the next press cycles back to "3 meals / 01 portion". This pattern repeats indefinitely (Memory function: Settings persist after power-off/on.) Once target meal count and portions are set, inaction for 10 seconds stops flashing to confirm.

After confirmation, the device dispenses the first meal and starts the timer.

Reset Timer:
After confirming the meal dispensing mode, the first meal is dispensed and the timer resets.

APP Settings Override:
Upon successful initial connection with the APP, any settings configured in the APP (including meal count, portion size, and scheduled dispensing times) will override the local device settings. The APP settings take precedence.
Subsequent Operations: After this, even if the device is restarted, the meal count and portion size defined in the APP will remain effective. The physical buttons will retain only two functions:

1. Take out the food
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the display stops flashing to confirm.

Maximum: 10 portions per meal After reaching "3 meals/10 portions", the next press switches to 4-meal mode.

In 4-meal mode, it resets to "4 meals / 01 portion". Each press increases the count.
If Auto-confirm: Same 10-second rule applies.

1. Put in dry batteries
2. Install the power cable. It is recommended to keep the device connected to the power supply continuously

3. Place in pet dry food

4. Dump the feeder, hold open the lid

5. Place in pet dry food

6. Be careful not cover this area with food to avoid affecting the installation

7. Install the lid

8. Keep the food outlet facing upwards to avoid the leakage

9. According to the arrow indication to install the lid

10. Install the bowl

1. Take out the bowl
2. Remove the food bucket

3. In 3-meal mode, it begins at "3 meals / 01 portion". Each press increases the portion count.
If Auto-confirm: If no action for 10 seconds, the