

X-TERRA 305 | 505



Field Guide



Power

Turns the detector On/Off.



Patterns

Scrolls through the different Discrimination Patterns.



All Metal

Toggles between the selected discrimination pattern and the All Metal pattern.



Minus

Adjusts settings, and scrolls to the left through the discrimination segments.



Menu

Enters the Menu. Accesses and scrolls through the detecting settings.



Plus

Adjusts settings, and scrolls to the right through the discrimination segments.



Pinpoint/Detect

Pinpoint assists in locating the exact position of a target prior to recovery. Detect exits menu settings and returns to detection.




Accept/Reject

Accepts or rejects discrimination segments.



Ground Balance

Accesses the Ground Balance Menu.



Battery

Indicates remaining power.



Headphones

Indicates headphones are connected.



Reject Identification

Appears when you reject a discrimination segment.



Sensitivity

Indicates that you are in the Sensitivity menu.



Ground Balance

Indicates that you are in the Ground Balance menu.



Noise Cancel

Indicates that you are in the Noise Cancel menu.



Threshold

Indicates that you are in the Threshold menu.



Volume

Indicates that you are in the Volume menu.



Tones

Indicates that you are in the Tones menu.