# Wireless Keyboard User Manual

Contains:user's guide\*1 keyboard case\*1 USB cable\*1



#### Product specifications

- 1. Bluetooth 3.0 interface standard
- 2. Operating Distance to 10 merers
- 3. Modulation system : GFSK
- 4. Operation Voltage: 3.0~4.2V
- 5. Operation Current : < 2.5mA
- 6. Standby Current : < 0.3mA
- 7. Sleeping Current : < 40uA
- 8. Charging Current : > 200mA
- 9. Standby Time : > 100 days
- 10. Charging Time: 3~4 houre
- 11. Battery Capacity: 150mA/420mA
- 12. Uninterrupted Working time: 100 hours
- 13. Lithium Battery Life: 3 years
- 14. Key Strength: 80±10g
- 15. Key life: 5million strokes
- 16. Operating Temperature : -10±55C

### **Getting Started Guide**

- 1. Button
- Power toggle switch : slide switch ON or OFF to control the device power turn on or turn off.
- Connect Button : Under the Power button turn on case,resdy to be connent to iPad.
- 2. Indicator
- Power indicator : urn on the power toggle switch. The state indicator light will be on for 4 seconds, then the light will go off.
- Charging indicator : indicator light will be on when the keyboard will be charing by USB.
- Blirtooth connect indicator : Press on the [connect] button,the[Bluetooth] indicator light will be blinking,indicator light will stay on until the keyboard connect with your device.
- $\bigcap\limits_{\text{\tiny case}}$  Uppercase and lowercase indicator : Indicator light will stay on under the uppercase

## Charging

When the battery is low,the power indicator light flahing,that means need to charge the bluetooth keyboard.

- 1. Connect the B end of the original USB cable to the keyboard.
- 2. Connect the A end of the USB cable to power adapter or A PC USB interface.
- When charging charging "Charge" indicator will light up, when the battery is full of "Charge" will automatically lights go out.

#### Bluetooth keyboard connection opertion steps

1. To set the keyboard power button to "ON" position, the power indicator light will light up for 4 seconds, and then Go out; Press the "Connect" to Connect a keyboard key, Bluetooth connention will twinkle lights when key Bluetooth is started, can be connected to the tablet The computer.



2. Open and unlock the tablet computer, click on the flat Board computer "Settings" icon.



 Select "Bluetooth" in "Settings" interface Emter the bluetooth Settings interface, click on the bluetooth Psaa to open the connection.



The tablet computer will automatically search is enabled Bluetooth devices wireless keyboard found signals, Click the project link.



## otice

- 1. It is recommended to turn off keyboard when it will be idled for long,to prolong the battery life.
- To priong battery's service life, it is recommended to charge the keyboard only when the power indicator is flashing. Eanh charing time is advisable to be ont less than 2hs.

## Energy-saving sleep mode

When the keyboard goes into sleep mode for 10 minutes without instructions press any key anb wait for 5 seconds. The keyboard will start up.

#### Troubleshooting

- 1. Make sure the power is turned on.
- 2. Make sure the keyboard is within operable range coverage.
- 3. Make sure the battery has electricity.
- 4. Make sure the setting of Bluetooth on tablet PC is turned on.
- Make sure the wireless keyboard is connected with Bluetooth.
- 6. Make sure the wireless keyboard and Bluetooth have been Paired.

# Charging

When the battery percentage is low,the power indicator flashes,indicating the Bluetooth keyboard needs to be charged.

- 1. Connect end B of original USB cable to the keyboard.
- 2. Connect end A of USB cable to power adapter to USB interface of computer,
- In charging the "Charge" charge indicator becomes ON, and when the battery is fully charged, the "Charge" indicator becomes OFF automatically.