RESTMO

SMART WATER FLOW METER



USER MANUAL

O-WM-2-BT



WARRANTY

Restmo provide one-year worry-free warranty. For any warranty claims within one year from the original order date, please email your order ID to Restmo Support and we will respond within 24 hours.

Scan QR code to extend your warranty to 5 years.



WARNINGS

- For outdoor use with clear cold water only.
- Filter can prevent water leakage and dirts damage. Clean filter regularly and replace if worn.
- When expecting freezing temperatures, device should be removed from the hose/faucet and stored indoors to avoid potential freeze damage.

Scan YouTube QR code or search RESTMO on YouTube to view set-up instructions video.



Scan WhatsApp OR code or send us WhatsApp messages to get online supports.



(-20°C ~ 70°C)

SPECIFICATIONS

Outlet Thread	3/4" BSP Male
Water Flow Rate	0.3~11 GPM

Inlet Thread 1" BSP Female

Water Flow Rate	0.3~11 GPN
	(1~41.9 L/min)
Max Water Consumption	99999 Gal

wax water consumption	33333	Gai
	(999	99 L)
Measurement Tolerance	=	± 5%
M. I'm Danie	0 44	o

Measurement Tolerance	± 5%
Working Pressure	8~116 ps
	(0.5~8 bar

Working Fressure	0° 110 psi
	(0.5~8 bar)
Bluetooth Range	≤230ft
	(70m)

	(70m
orking Temperature	37°F~ 149°F
	(3°C~65°C

Storage Temperature-4°F~ 158°F

Maximum Humidity 90%

	(0.5~6.0)
luetooth Range	≤230
	(70r
orking Temperature	37°F ~ 149°
	(3°C~ 65°C

working voltage	L. IV 0. IV
Low Voltage Indicator	<2.4V±0.1V
Waterproof Grade	IP54
Battery	2 x AAA Alkaline Batteries
	(not included)

211/ 211/

FEATURES

Working Voltage

- Bluetooth connection & smart life app
- · Adaptive screen orientation
- Screen backlight
- Simple installation & operation
- Switchable unit (gallon/liter)
- · Low battery indication
- · 4 modes of water flow measurement:
 - (a) Real-time water flow rate
 - (b) Last-time water consumption
 - (c) Daily water consumption
 - (d) Total water consumption

BATTERY INSTALLATION

Step 1:

Pull out the battery tray on the back of flow meter.

Step 2:

Insert two AAA alkaline batteries

and replace the tray.

Step 3:

Ensure batteries are fully inserted

by correct directions.

Note:

- DO NOT use wet hands to open battery tray. Always keep your hands dry when install batteries.
- Replace with new batteries if low battery indicator displays.

DEVICE PAIRING

Step 1:

Download and install the Smart Life APP. Log in or create your account.






Step 2:

If the device has not been connected yet, the LCD of the Pair Mode will display Uncon and '1' flashes.



If the device has already been connected, the LCD of the Pair Mode will display the current time. Long press the button until the display turns to Uncon.




Step 3:

Click "+" and "Add Device" through Smart Life APP.

Pair the "RESTMO BT Water Flow Meter".

APP CONTROL



Note:

On the Smart Life APP, you can view the single water usage records within 24 hours and total year water usage up to 3 years.

It can save up to 100 records if the device is disconnected. When the data records exceed 100, The earliest records will be automatically cleared.

DEVICE SETUP/REMOVE


Device Setup



Note:

When Rotate Setting is AUTO, the screen orientation will be automatically changed according to gravity.


Device Information



Note:

Click "Remove Device" can clear the data and remove the device from your Smart Life account.

DEVICE INSTALLATION



OPERATION

Short press the button to change measure modes.

Long press the button (3secs) at flow mode to switch measurement units from gallon to liter.

Long press the button (3secs) at consumption/avg/total modes to reset data.

Long press the button (3secs) at pair mode to activate device pairing.

The LCD screen goes to sleep if there is no operation or water flow within 1min.

FLOW MODE:

Flow mode displays the real-time water flow rate

Long press the button to switch measurement units from gallon to liter.



Button



Note:

If the water flow rate is higher than the 11GPM (41.9LPM), it will

display H.H or HH.H.

CONSUMPTION MODE:

Consumption mode displays the last-time water consumption.

Long press the button to reset.



Button

3sec

Note: Reset Consumption

Consumption mode counts the last-time water usage and always resets to zero automatically after water flow stops more than 1 minute

DAILY MODE:

Daily mode displays today's water consumption.

Long press the button to reset.







Reset Daily

TOTAL MODE:

Total mode displays the total water consumption.

Long press the button to reset.



Button



Reset Total


Note:

Total mode will never reset until you manually reset it. The data will be recorded even you change the battery.

PAIR MODE:

Pair mode can pair the device with the smart phone.

- When the device is paired with a smart phone, it will display the current time. Long press the button can activate device pairing.
- When the device is unpaired, it will display "Uncon".



TROUBLESHOOTING

Problem	Possible factors	Solution may help
Cannot	·Bluetooth of smart	·Turn on the
connect the	phone is off.	Bluetooth of the
device	·Smart Life APP is	smart phone.
	not latest version.	·Download the
	· Device is already	latest version
	connected with	Smart Life APP via
	another smart	Apple or Google
	phone.	APP store.
		·Press the device
		button and turn it to
		Pair Mode. Long
		press the button
		and activate device
		pairing.

Problem	Possible factors	Solution may help
Screen	The rotate setting	Use the Smart Life
orientation	is locked to UP or	APP to change the
is not	DOWN.	rotate setting to
changed		AUTO.
automati-		
cally.		
Flow unit is		·Long press the
not		device button at
switchable.		Flow Mode can
		switch the flow unit
		from GAL to L.
		·Use the Smart Life
		APP to switch the
		flow unit.

	 derential many ment
Water	·The single water
usage is	usage (one by one)
not	will be cleared after
recorded.	24 hours.
	·The month water
	usage will be
	cleared after 1
	year.
	·The year water
	usage will be
	cleared after 3

years.

Problem Possible factors Solution may help

Condensa-	Air condenses	The fog disappears
tion	inside the screen	when the tempera-
on the	due to the	ture rises, or leave
screen	temperature	it stand for a period
	difference between	of time.
	inside and outside.	
Water	Filter washer lost	·Check if filter
meter is	or damaged.	washer is in place.
leaking		·Check if filter
		washer is clean
		and undamaged.

Possible factors

Solution may help

· Faucet connection is hand tight.

Problem

Problem	Possible factors	Solution may help
Water	The counting	· Stones or dirt block
meter does	flywheel does not	the flywheel. If so,
not count	rotate properly or	clean the stones or
water flow	filter is clogged.	dirt.
		· The flywheel is
		damaged. Contact
		customer service
		for a new replace-
		ment.
		· Check if the filter is
		clogged, if so,
		clean or replace
		the filter.

Problem	Possible factors	Solution may help
LCD	Battery is dead or	· Replace with 2
screen	is not installed	new AAA Alkaline
does not	properly.	Batteries.
display		· Make sure the
		battery compart-
		ment is clean and
		battery is installed
		with correct
		direction.
		· Tightly screw the
		battery cap.

Problem	Possible factors	Solution may help
Water	Water meter	Here are tips to
meter does	counting has ±5%	test the counting
not count	tolerance.	performance:
correctly		· Make sure the
		counting unit
		(liter/gallon) is
		correct.
		· Must install a
		garden hose on the
		outlet and make
		sure the water flow
		is 0.3GPM (1LPM)
		at least.

Problem	Possible factors	Solution may help
Display	Consumption mode	To count continu-
always	counts the last-time	ous water usage,
automati-	water usage and	switch to total
cally resets	always resets to	mode. Total mode
to zero	zero automatically	will not automati-
	after water flow	cally reset to zero
	stops more than 1	unless you
	minute.	manually reset.
Display	Water flow rate is	Turn down the
keeps	higher than 11GPM	faucet.

H.HH or (41.9LPM).

HH.H.

RESTMO

Enjoy Your REST MOMENT

Support@restmo-link.com

a +1866-876-6888

+1929-329-4398

www.restmo.online