

**Model NO. : iE268**

**Model Name: NAVIGATION MULTIMEDIA RECEIVER**

## MainMenu



### 1.All Menus

**Radio:** Converts to the last played radio mode.

**SiriusXM:** Listen to the channel

**Audio Settings:** Sound setting

**Android Auto:** Runs android auto function.

**Apple CarPlay:** Runs Apple CarPlay function.

**Settings:** Moves to the settings menu.

## 2. All Menus

**BT Phone:** Answer and make a call

**Bluetooth:** Connect the mobile phone to play mobile audio

**USB:** Converts to the last played USB mode.

**Camreas:** Show the camera picture

**Display Off:** The device enters the screen off state

## Radio




**【FM】:** Click to switch FM mode.

**【AM】:** Click to switch AM mode.

**【Distant/Loc】 :** Search the range of channels

**【Auto】 :** Channel search mode


Press : Manual input channel

## Siriusxm



**【SXM】:** Click to switch FM

Press : Manual input channel

Press : SiriusXM Settings

## Audio Settings



**【Settings】:** You can adjust the sound position by clicking the up / down / left / right arrow.



**【Equalizer】:** You can set equalizer by yourself and save them




**【Crossover】:** You can adjust Slope、Frequency、Level of these parameters



**【Factory EQ】:** You can choose a Factory EQ model.

## Android Auto



## Apple CarPlay

### Note



- The Bluetooth source of the machine is not available when the carplay is connected.





### Connect wireless carplay

1. press [settings-device-device list] to wireless carplay connection interface
2. Click [add a device] to search for available wireless carplay devices. Press the cancel button to stop the search.

3. Click the  button to connect to the paired device, and click the  button to delete the paired device.

## Settings

Press the [Settings] icon on the All Menus interface to enter the setup menu interface.



Press[Clock]: You can set the device time



Press[Microphone]: You can set the Microphone

Press[System Beep Volume]: You can set the beep switch

Press[Language]: You can set the Language



Press[Auto Brightness]: You can set auto brightness

Press[Display Brightness]: You can set the brightness of the screen

Press[Face Button Color]: You can set the color of the panel light

Press[Face Button Brightness]: You can set the color of the light on the engine panel

Press[Background]: You can set the background of the machine



Press[Camera Setup]: You can set the Camera

Press[Mute Audio Playback in Reverse]: Your reverse will be silent.



Press[Switch to Forward Camera after reverse]: When you're done backing up, another camera will appear

## BT Phone



### Phone Dial

- Click on the display keyboard to make a call



### Favourites

- Click to display favorites
- If you do not have any favorites, you can click on add favourites from contats to add

favorites contacts



### Call History

- Show cell phone records



### Contacts

- Tap to show your phone contacts



## Settings

Click to display the device connected to the machine

## Bluetooth

When Bluetooth is connected, click to play BT music.



Press[Previous button]: You can switch to the previous one

Press[Next button]: You can switch to the next song

## USB

When the USB disk is inserted, the USB music icon is highlighted. Click USB music to enter the USB music interface.



### **Pause**

- You can pause the playing file
- Press [ || ] on screen .

### **Play**

- Press [ ▶ ] on screen to play it again.

### **Previous button**

When it is pressed for a short time.

- Press the previous button to switch to the previous video (playing progress does not exceed 5 seconds).
- Press the previous button, the currently playing video will restart (Play progress exceeds 5 seconds).

When it is pressed and held

- Rewind the currently playing video

### **Next button**

When it is pressed for a short time.

- Press a button to cut to the next video

When it is pressed and held.

- Fast forward the currently playing video

### **Repeat**

- Switch the repeat mode of the song: Repeat All, Repeat Folder, and Repeat Track.

### **File Button**


- You can choose to play music, video or pictures

### **Search Button**

- You can search for the usb file you are looking for

## Cameras

Press [Camera] interface show the camera picture..



FCC Compliance Statement: This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The distance between user and products should be no less than 20cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.