


In the box



1



2



3



4



5



6

1 STB

2 Quick Guide


3 Power Adapter

4 Battery

5 HDMI Cable

6 Remote Control

Device Information



7



4



7



2



5



3



4



6



8

1 TYPE C

2 DC 12V

3 OPTICAL

4 HDMI


5 LAN

6 AV

7 USB

8 MICRO SD

Setup Diagram



Remote Control



Do more on your TV with your voice

Search for shows, get recommendations, even control your TV - faster - with your voice. Ask Google for a little help on your big screen.

Important notice

The batteries of your remote control are 2 x AAA type, 1.5V DC. Do not mix different types of batteries or new and old batteries. Do not use rechargeable batteries. In order to avoid any risk of explosion, observe polarities indicated inside the battery compartment. Replace only with the type of batteries specified above. Do not subject to excess heat such as SUN and Fire, do not recharge them. If you are not using the remote control for a long period of time, remove the batteries. Please respect the environment and prevailing regulations! Batteries must be collected separately from other refuse! Before you dispose of batteries, ask your dealer whether they are subject to special recycling and if he will accept them for disposal.

Remote Control




Pairing guide

Long press Back+Home button at the same time, until the red light flashes quickly, then release, that means RCU enter the pairing mode. Waiting for few seconds and stop pressing any buttons, until it pop up the message of pairing successfully.

Android TV


Complete the on-screen setup

Follow the on-screen instructions using your remote to navigate through the setup process.



Android TV

Android TV™ makes it easier to get more from your TV. Choose from 400,000+ movies and shows from across streaming services. Ask Google to control your TV, get recommendations of what to watch, dim the lights, and more with your voice. Cast photos, videos, and music from smart devices to your TV with Chromecast built-in™.



Specification

Hardware	
Chipset	Amlogic S905Y4
RAM	2GB DDR
Flash	eMMC 8GB
Video	
Video Decoding	AV1 MP-10@L5.1 up to 4Kx2K@60fps VP9 Profile-2 up to 4Kx2K@60fps H.265 HEVC MP-10@L5.1 up to 4Kx2K@60fps AVS2-P2 Profile up to 4Kx2K@60fps H.264 AVC HP@L5.1 up to 4Kx2K@30fps H.264 MVC up to 1080P@60fps MPEG-4 ASP@L5 up to 1080P@60fps (ISO-14496) WMV/VC-1 SP/MP/AP up to 1080P@60fps AVS-P16(AVS+)/AVS-P2 JIZhun Profile up to 1080P@60fps MPEG-2 MP/HL up to 1080P@60fps (ISO-13818) MPEG-1 MP/HL up to 1080P@60fps (ISO-11172) RealVideo 8/9/10 up to 1080P@60fps
Video File Format	Support *.mkv, *.wmv, *.mpg, *.mpeg, *.dat, *.avi, *.mov, *.iso, *.mp4, *.rm, *.jpg, *.bmp, *.gif etc...
Video Output	HDMI 2.1 , HDCP2.2
Aspect Ratio	Auto, Full screen
Video Resolution	480i/p, 576i/p, 720i/p, 1080i/p and 4Kx2K
Power	
DC Input Range	12V / 1.2A
Power Consumption	Maximum 14.4W

Safety Information



CAUTION!

NOTICE: To prevent fire and electric shock, do not expose this device to rain or moisture. In order to avoid any possible risk of electric shock, never attempt to open the unit. In case of the unit breaking down, repair of the unit should be carried out by qualified technicians. No part of this unit should be repaired by users.

WARNING!

- Place the device in a well-ventilated location to prevent accumulation of internal heat.
- Protect the device from high temperatures, humidity, water and dust.
- Do not place any objects that might damage your unit near it (e.g. liquid filled objects or candles).

Google, Google Play, Android TV, Chromecast built-in and other marks are trademarks of Google LLC.

Google Assistant is not available in certain languages and countries.



Setup Guide

A1

