



## SMART LED FLOOR LAMP USER MANUAL

24-Hour Service: [outonofficial@outlook.com](mailto:outonofficial@outlook.com)  
Website: [www.outonglobal.com](http://www.outonglobal.com)

|               |                                                                                                  |    |      |    |    |
|---------------|--------------------------------------------------------------------------------------------------|----|------|----|----|
| Manufacturer: | Outon Lighting Co., Ltd.                                                                         | CE | RoHS | UK | AN |
| Address:      | Room 303-315, Building 1, No. 3 Hefei Road, Hefei Town, Changshu City, Jiangsu Province, China   | CE | RoHS | UK | AN |
| Product:      | Smart LED Floor Lamp                                                                             | CE | RoHS | UK | AN |
| Address:      | 4225, 2nd Floor, Hefei Office Building, No. 81, Shanghai Road, Hefei City, Anhui Province, China | CE | RoHS | UK | AN |
| Model No.:    | MF18806                                                                                          | CE | RoHS | UK | AN |



### Customer Service

Dear Customer,  
We sincerely thank your business and for becoming our valued customer. We are honored to participate in creating a warm and comfortable home for you. As a reliable seller, we strive to provide customers with **100% satisfactory products and service**, so we hope your shopping experience can be pleasant. If you find any damages or dissatisfaction after receiving the product you are welcome to contact us via [outonofficial@outlook.com](mailto:outonofficial@outlook.com) and we will provide you with a 100% satisfactory solution.

If you would like to register for a **1-year warranty** extension, please contact us **within one month** after purchase.

If you are satisfied with our products and services, We hope you can leave us an **honest comment** at your convenience. We think your comment will be a reference for other users in the future, and other customers will be very grateful to you.

SPU: H-SFD01



Scan the QR code to  
watch the assembly video

### Introduction

Thank you for choosing OUTON LED Floor Lamp. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact us by email with your Amazon order number and details.


#### Package Contents

- 1 × LED Floor Lamp
- 1 × Lamp Base
- 1 × User Manual
- 4 × Iron Pipes
- 1 × Remote Controller
- 1 × Power Adapter with Cable

#### Characteristics

- Brightness and color temperature stepless adjusted.
- Memory function, restore to the luminance of last time close light when open light again, don't need to repeat adjusting the light.
- Adjustable lamp head.
- Heavy base.
- Professional eyes-protect light, which make up of no blue light harmful and no flicker LED, It is less harmful for long time use.
- The rendering of real colors. The color rendering index ( Ra ) of this lamp is more than 95, it is good for painter, designer and so on.

#### Product Structure




### Installation

**Step 1:** Connect the tube to the lamp holder. Rotate clockwise.


**Step 2:** Connect the tube to the other. Turn the iron tube clockwise.

**Step 3:** Finally connect the iron pipe with the wire. The light rotates clockwise.

The installation is finished, then plug in adapter, you can touchcontrol or remotecontrol the light.



- ⬆ Increase Brightness
- ⬇ Decrease Brightness
- M Change Color Temperature
- ⏸ Short Press for power ON/OFF Long Press for 1 Hour Setting



- ⌚ Set a 1h timer, light get several flicker mean 1h timer is successful set.
- ⏸ Short press to turn on/off light.
- ⬆ Short/Long press to enhance the CCT (3000K to 6000K) as you like.
- ⬇ Short/Long press to lower the CCT (6000K to 3000K) as you like.
- ⬆ Short/Long press to enhance the brightness as you like.
- ⬇ Short/Long press to lower the brightness as you like.
- ★ Short press to be the max brightness and CCT immediately.
- ⌚ Short press to enter leisure mode.
- 📖 Short press to enter reading mode.
- ⌚ Short press to enter breastfeed mode.
- ⌚ Short press to enter night light mode.
- ⌚ Short press to enter work mode.



### How to match remote control with the lamp:

#### STEP 1

Load the remote control with 2×1.5V AAA batteries.




#### STEP 2

Long press on the "On/Off" button and the indicator light flicker.



#### STEP 3

Plug the adapter into a socket and the flickering of the light means matching successfully.



### How to decode remote control and the lamp:

Reconnect power after pulling off plug



Long press the "1H" button and the light flicker means decoding successfully.



## US

### SPECIFICATION

|                |                       |
|----------------|-----------------------|
| Name:          | Floor Lamp            |
| Model:         | MF18806               |
| Material:      | Iron + PC             |
| Wattage:       | 15W                   |
| Luminous Flux: | 1500lm                |
| Dimmable:      | 10%-100% full dimming |
| Input Voltage: | AC 220-240V-50/60Hz   |

### REMOTE CONTROL

The remote control's effective distance is within 15m. It's magnetic and you could stick it to the lamp pole.

|   |   |                                                                     |
|---|---|---------------------------------------------------------------------|
| 1 | ⏸ | ON/OFF                                                              |
| 2 | ⌚ | 1 Hour Timer                                                        |
| 3 | ⬆ | Maximum Brightness/ Brightness Adjustment/ Switch Color Temperature |
| 4 | ⬇ | Five Working Modes                                                  |

### HOW TO USE

- ⬆ Increase Brightness
- ⬇ Decrease Brightness
- M Switch Color Temperature
- ⏸ Short Press for power ON/OFF Long Press for 1 Hour Setting

### NOTICE

- Read the user manual before using the lamp.
- Please turn off the power when the lamp is not at work.
- Do not touch the lamp with wet hands and keep it away from fluids.
- Please clean the lamp with dry cloth and do not use chemicals and household cleaners.
- To ensure long lifespan, keeping the lamp away from damp, wet and hot environments.
- Do not use the lamp when the cord is frayed.
- Do not use the lamp when exceeding the specified voltage.
- Do not dismantle or repair the lamp without qualification to operate by your local regulations.
- Check for transport damage after receiving the packaged lamp. Contact us directly if there is any product issue by [outonofficial@outlook.com](mailto:outonofficial@outlook.com)

### WARRANTY

All lamps are promised to have 1-year warranty. No matter what kind of problems you encounter, you can contact [outonofficial@outlook.com](mailto:outonofficial@outlook.com) at any time and get our support.

## UK/AU

### SPECIFICATION

|                |                       |
|----------------|-----------------------|
| Name:          | Floor Lamp            |
| Model:         | MF18806               |
| Material:      | Iron + PC             |
| Wattage:       | 15W                   |
| Luminous Flux: | 1500lm                |
| Dimmable:      | 10%-100% full dimming |
| Input Voltage: | AC 220-240V-50/60Hz   |

### REMOTE CONTROL

The remote control's effective distance is within 15m. It's magnetic and you could stick it to the lamp pole.

|   |   |                                                                     |
|---|---|---------------------------------------------------------------------|
| 1 | ⏸ | ON/OFF                                                              |
| 2 | ⌚ | 1 Hour Timer                                                        |
| 3 | ⬆ | Maximum Brightness/ Brightness Adjustment/ Switch Color Temperature |
| 4 | ⬇ | Five Working Modes                                                  |

### HOW TO USE

- ⬆ Increase Brightness
- ⬇ Decrease Brightness
- M Switch Color Temperature
- ⏸ Short Press for power ON/OFF Long Press for 1 Hour Setting

### NOTICE

- Read the user manual before using the lamp.
- Please turn off the power when the lamp is not at work.
- Do not touch the lamp with wet hands and keep it away from fluids.
- Please clean the lamp with dry cloth and do not use chemicals and household cleaners.
- To ensure long lifespan, keeping the lamp away from damp, wet and hot environments.
- Do not use the lamp when the cord is frayed.
- Do not use the lamp when exceeding the specified voltage.
- Do not dismantle or repair the lamp without qualification to operate by your local regulations.
- Check for transport damage after receiving the packaged lamp. Contact us directly if there is any product issue by [outonofficial@outlook.com](mailto:outonofficial@outlook.com)

### WARRANTY

All lamps are promised to have 1-year warranty. No matter what kind of problems you encounter, you can contact [outonofficial@outlook.com](mailto:outonofficial@outlook.com) at any time and get our support.

## DE

### SPEZIFIKATION

|                   |                       |
|-------------------|-----------------------|
| Name:             | Stehleuchte           |
| Modell:           | MF18806               |
| Material:         | Eisen + PC            |
| Wattleistung:     | 15W                   |
| Lichtstrom:       | 1500lm                |
| Dimmbar:          | 10%-100% voll dimmbar |
| Eingangsspannung: | AC 220-240V-50/60Hz   |

### FERNBEDIENUNG

Der effektive Abstand der Fernbedienung beträgt 15m. Es ist magnetisch und man könnte es an den Lampenmast kleben.

|   |   |                                                                     |
|---|---|---------------------------------------------------------------------|
| 1 | ⏸ | AN/AUS                                                              |
| 2 | ⌚ | 1 Stunde Zeit                                                       |
| 3 | ⬆ | Maximale Helligkeit/Helligkeitseinstellung/ Farbtemperatur wechseln |
| 4 | ⬇ | Fünf Arbeitsmodi                                                    |

### WIE BENUTZT MAN

- ⬆ Erhöhen Sie die Helligkeit
- ⬇ Diminuisci la luminosità
- M Farbtemperatur wechseln
- ⏸ Kurz drücken, um das Gerät ein- / auszuschalten Lang drücken für 1 Stunde Einstellung

### BEACHTEN

- Lesen Sie die Bedienungsanleitung, bevor Sie die Lampe verwenden.
- Bitte schalten Sie die Stromversorgung aus, wenn die Lampe nicht funktioniert.
- Berühren Sie die Lampe nicht mit nassen Händen und halten Sie sie fern aus Flüssigkeiten.
- Bitte reinigen Sie die Lampe mit einem trockenen Tuch und verwenden Sie sie nicht Chemikalien und Haushaltsreiniger.
- Um eine lange Lebensdauer zu gewährleisten, halten Sie die Lampe von Feuchtigkeit fern, nasse und heiße Umgebungen.
- Verwenden Sie die Lampe nicht, wenn das Kabel ausgefranst ist.
- Verwenden Sie die Lampe nicht, wenn die angegebene Spannung überschritten.
- Zerlegen oder reparieren Sie die Lampe nicht ohne Einschränkung gemäß den örtlichen Vorschriften arbeiten.
- Nach Erhalt der Verpackung auf Transportschäden prüfen Lampe. Kontaktieren Sie uns direkt, wenn ein Produktproblem vorliegt [outonofficial@outlook.com](mailto:outonofficial@outlook.com)

### GARANTIE

Auf alle Lampen gewähren wir 1 Jahr Garantie. Egal, welche Art von Problemen Sie haben, Sie können sich jederzeit an [outonofficial@outlook.com](mailto:outonofficial@outlook.com) wenden und unsere Unterstützung in Anspruch nehmen.

## FR

### SPÉCIFICATION

|                                         |                               |
|-----------------------------------------|-------------------------------|
| nom :                                   | Lampadaire                    |
| Modèle :                                | MF18806                       |
| Matériau :                              | fer + PC                      |
| Puissance en watts :                    | 15W                           |
| Flux lumineux :                         | 1500lm                        |
| Dimmable par un variateur d'intensité : | 10%-100% entièrement dimmable |
| Tension d'entrée :                      | AC 220-240V-50/60Hz           |

### TÉLÉCOMMANDE

La distance effective de la télécommande est à moins de 15m. Il est magnétique et vous pouvez le coller au poteau de la lampe.

|   |   |                                                                                 |
|---|---|---------------------------------------------------------------------------------|
| 1 | ⏸ | ALLUMÉ ÉTEINT                                                                   |
| 2 | ⌚ | 1 heure                                                                         |
| 3 | ⬆ | Luminosité maximale/Réglage de la luminosité/ Changer la température de couleur |
| 4 | ⬇ | Cinq modes de travail                                                           |

### COMMENT UTILISER

- ⬆ Augmenter la luminosité
- ⬇ Diminuisci la luminosità
- M Changer la température de couleur
- ⏸ Appuyez brièvement pour allumer/éteindre Appuyez longuement pendant 1 heure

### REMARQUER

- Lisez le manuel d'utilisation avant d'utiliser la lampe.
- Veuillez éteindre l'alimentation lorsque la lampe ne fonctionne pas.
- Ne touchez pas la lampe avec les mains mouillées et éloignez-la des fluides.
- Si vous nettoyez la lampe avec un chiffon sec et ne pas utiliser produits chimiques et nettoyants ménagers.
- Pour assurer une longue durée de vie, en gardant la lampe à l'abri de l'humidité, environnements humides et chauds.
- N'utilisez pas la lampe lorsque le cordon est effiloché.
- N'utilisez pas la lampe lorsque vous dépassez la tension spécifiée.
- Ne démontez pas ou ne réparez pas la lampe sans qualification pour fonctionner selon vos réglementations locales.
- Vérifiez les dommages dus au transport après avoir reçu l'emballage lampe. Contactez-nous directement en cas de problème avec le produit [outonofficial@outlook.com](mailto:outonofficial@outlook.com)

### GARANTIE

Toutes les lampes bénéficient d'une garantie d'un an. Quel que soit le type de problème rencontré, il est possible de contacter [outonofficial@outlook.com](mailto:outonofficial@outlook.com) à tout moment et obtenir notre aide.

## IT

### SPECIFICA

|                       |                                    |
|-----------------------|------------------------------------|
| Nome:                 | Lampada da terra                   |
| Modello:              | MF18806                            |
| Materiale:            | fer + PC                           |
| Potenza:              | 15W                                |
| Flusso luminoso:      | 1500lm                             |
| Dimmerabile:          | 10%-100% completamente dimmerabile |
| Tensione di ingresso: | AC 220-240V-50/60Hz                |

### TELECOMANDO

La distanza effettiva del telecomando è di 15m. È magnetico e potresti attaccarlo al palo della lampada.

|   |   |                                                                                   |
|---|---|-----------------------------------------------------------------------------------|
| 1 | ⏸ | ACCESSO SPENTO                                                                    |
| 2 | ⌚ | 1 ora                                                                             |
| 3 | ⬆ | Luminosità massima/Regolazione della luminosità/ Cambia la temperatura del colore |
| 4 | ⬇ | Cinque modalità di lavoro                                                         |

### COME USARE

- ⬆ Aumenta la luminosità
- ⬇ Diminuisci la luminosità
- M Cambia la temperatura del colore
- ⏸ Pressione breve per accensione/spegnimento Premere a lungo per l'impostazione di 1 ora

### AVVISO

- Leggere il manuale dell'utente prima di utilizzare la lampada.
- Spegnere l'alimentazione quando la lampada non è in funzione.
- Non toccare la lampada con le mani bagnate e tenerla lontana dai fluidi.
- Si prega di pulire la lampada con un panno asciutto e non utilizzarla prodotti chimici e detersivi per la casa.
- Per garantire una lunga durata, mantenendo la lampada lontana dall'umidità, ambienti umidi e caldi.
- Non utilizzare la lampada quando il cavo è sfilacciato.
- Non utilizzare la lampada se si supera la tensione specificata.
- Non smontare o riparare la lampada senza essersi qualificati operare secondo le normative locali.
- Verificare la presenza di danni durante il trasporto dopo aver ricevuto l'imballaggio lampada. Contattaci direttamente in caso di problemi con il prodotto [outonofficial@outlook.com](mailto:outonofficial@outlook.com)

### GARANZIA

Tutte le lampade hanno una garanzia di 1 anno. Indipendentemente dal tipo di problema riscontrato, è possibile contattare [outonofficial@outlook.com](mailto:outonofficial@outlook.com) in qualsiasi momento e ricevere il nostro supporto.

## ES

### ESPECIFICACIÓN

|                     |                              |
|---------------------|------------------------------|
| Nombre:             | Lámpara de pie               |
| Modelo:             | MF18806                      |
| Material:           | Hierro + PC                  |
| Potencia:           | 15W                          |
| Flujo luminoso:     | 1500lm                       |
| Regulable:          | 10%-100% regulación completa |
| Tensión de entrada: | AC 220-240V-50/60Hz          |

### CONTROL REMOTO

La distancia efectiva del control remoto es de 15m. Es magnético y puedes pegarlo al poste de la lámpara.

|   |   |                                                              |
|---|---|--------------------------------------------------------------|
| 1 | ⏸ | ENCENDIDO/APAGADO                                            |
| 2 | ⌚ | 1 hora de tiempo                                             |
| 3 | ⬆ | Brillo máximo/Ajuste de brillo/ Cambiar temperatura de color |
| 4 | ⬇ | Cinco modos de trabajo                                       |

### CÓMO UTILIZAR

- ⬆ Aumentar el brillo
- ⬇ Disminuir el brillo
- M Cambiar temperatura de color
- ⏸ Pulsación corta para encender/apagar Pulsación larga para ajuste de 1 hora

### DARSE CUENTA

- Lea el manual del usuario antes de usar la lámpara.
- Apague la alimentación cuando la lámpara no esté funcionando.
- No toque la lámpara con las manos mojadas y manténgala alejada de los fluidos.
- Limpie la lámpara con un paño seco y no la utilice: productos químicos y limpiadores domésticos.
- Para garantizar una larga vida útil, manteniendo la lámpara alejada de la humedad, ambientes húmedos y calientes.
- No utilice la lámpara cuando el cable esté deshilachado.
- No use la lámpara cuando exceda el voltaje especificado.
- No desmonte ni repare la lámpara sin estar calificado para opere según las normativas locales.
- Compruebe si hay daños de transporte después de recibir el paquete. Lámpara. Contáctenos directamente si hay algún problema con el producto por [outonofficial@outlook.com](mailto:outonofficial@outlook.com)

### GARANTÍA

Todas las lámparas tienen 1 año de garantía. No importa qué tipo de problemas que encuentre, puede ponerse en contacto con [outonofficial@outlook.com](mailto:outonofficial@outlook.com) en cualquier momento y obtener nuestro apoyo.

## JP

### 仕様

|          |                 |
|----------|-----------------|
| 名 前:     | フロアランプ          |
| マ デ ル:   | MF18806         |
| 材 質:     | 鉄+PC            |
| ワ ッ ト 数: | 15W             |
| 光 束:     | 1500lm          |
| 調 光 可 能: | 10% ~ 100% フル調光 |
| 入 力 電 圧: | AC 100V/50-60Hz |

### リモコン

リモコンの有効距離は15m以内。リモコンはマグネット式で、電柱に貼り付けることもできる。

|   |   |                     |
|---|---|---------------------|
| 1 | ⏸ | オン/オフ               |
| 2 | ⌚ | 1 時間タイマー            |
| 3 | ⬆ | 最大輝度 / 輝度調整 / 色温度切替 |
| 4 | ⬇ | 5 つの作業モード           |

### 使用 方法

- ⬆ 明るさを上げる
- ⬇ 明るさを下げる
- M 色温度の切り替え
- ⏸ 短押しで電源ON/OFF 長押しで1時間設定

### 注 意 事 項

- ランプを使用する前に取扱説明書をお読みください。
- ランプを使用しないときは、電源を切ってください。
- 濡れた手でランプに触れる、液体に近づけないでください。
- 化学薬品や家庭用洗剤は使用しないでください。
- 長寿命を確保するために、ランプを湿気、濡れ、高温の環境から遠ざけてください。
- コードがはつれた状態で使用しないでください。
- 指定された電圧を超えてランプを使用しないでください。
- あなたの地域の規制によって動作する資格のないランプを分解または修理しないでください。
- 包装されたランプを受け取った後、配送の損傷をチェックしてください。製品に問題がある場合は、[outonofficial@outlook.com](mailto:outonofficial@outlook.com)まで直接ご連絡ください。

### 保証

すべてのランプは1年間の保証を約束します。どのような問題が発生しても、[outonofficial@outlook.com](mailto:outonofficial@outlook.com)。

### Fcc and ISCED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence L'exploitation est autorisée aux deux conditions suivantes:  
(1) l'appareil ne doit pas produire de brouillage,  
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-005. Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

la distance entre l'utilisation et l'appareil ne doit pas être inférieure à 20 cm.

### FCC and IC Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

la distance entre l'utilisation et l'appareil ne doit pas être inférieure à 20 cm.