



BOULT AUDIO

OMEGA USER MANUAL


For better sound quality experience, suggest use
IOS 8.0/ Android 4.3 or above operating system.

Product Introduction

Multi-function Button



LED indicator



**TYPE-C
Charging Port**

Product Specification

Model No:	Omega
Bluetooth version:	Bluetooth V5.2
Supported mode:	HFP/HSP/A2DP/AVRCP
Sensitivity:	102 dB+3dB
Signal distance:	10m (in an ideal environment without any large obstacles)
Charging time:	charge the charging case for about 1.5 hours, and charge the earphone for about 1 hour

Pairing Method

1. Lift the left and right earphones from the charging case to turn on the earphones. and then the two earphones will automatically enter the pairing mode. The two earphones will be automatically connected with in 10 seconds, Then open the phone Bluetooth device and search for pairing name: Boulton Audio Airbass.
2. Bluetooth pairing name: Boulton Audio Airbass

Charging Operation

1. Plug the type-c charging cable to the type-c charging port of the charging case.
2. Charging the earphone: put the earphone into the charging case and can be charged automatically. when charging, the green light flash, after charging completed, the four green light all turn on.

Change Eartips

Please change your eartips size according to the noise reduction effect and comfortability



Function

1. Power on

Take the earphone out of the charging case and it will power on automatically, or long press the left and right multi-function of the earbuds for 2 seconds.

2. Power off

Put the earphones in charging case and it will power off automatically, or long press the left and right multi-function of the earbuds for 5 seconds.

3. Autopairing

If the earphone is previously paired it will automatically pair with the device when turned on.

4. Play/Pause

While using the earphone single tap on left/right earbud touch to play/pause.

5. Next/previous

Double tap the left earphone multi-function touch to play previous music track and double click the right earphone multi-function button to play next music track.

6. Answer call

Single tap on left/right earbud to answer the incoming call.

7. Hang up call

Double tap on left/right earbud when on ongoing call to hang up that call.

8. Call rejection

During an incoming call, double click on either earbuds to reject the call.

9. ANC Mode

Long press on right earbud for 3 seconds to toggle ANC On/ANC Off/Transparent mode.

10. Volume +/-

Triple tap the left multi-function button to decrease the volume and triple tap on right multi-function button to increase the volume.

11. Music Modes

Tap four times on right earbuds' touch to toggle 3 music modes - Rock Mode/Bass Boost/Hi-Fi Music

12. Gaming Mode

Tap four times on left earbuds' touch to toggle between Gaming mode (with lower latency) and Music mode (with better battery life)

13. Voice assistant

When earphones are connected, long press left earphone's touch to trigger voice assistant (Google/Siri)

Precautions

1. Please charge in a safe environment. When charging the charging case, please separate the charging case from the USB Charging cable as soon as possible after the charging indicator is off, so as to avoid damage to the charging case caused by the long time of charging.
2. When the music is playing, please adjust the music to the Appropriate volume to avoid long-term damage to the hearing under the condition of high volume.
3. Try to avoid using the earphone where there is interference source otherwise it may affect the earphone signal.
4. Try to avoid using the earphone in a corrosive environment, so as not to affect the function of the earphone.

Tips: when you use the Bluetooth earphones t listen to music or talk, please pay attention to adjust the volume, so as not to affect your listening too much!