



Product Instruction for

M455dn/M454dn M454dw
M480f/M479 M479dw/M479dn M479fdw
M255dw/M282/283fdw
MFP M155/182/183NW




Product Instruction UK

The following steps for printers above:

Scenario 1


1




Messages Auto Switching


When the first time you install the cartridge, your printer will pop up the above messages. Press the "OK" button to continue.

2



When your printer displays "Ready", you can start to print. The cartridge chip is recycled and it will show  icon, but it will NOT affect printing.

3





When request printing from a PC, it will prompt above message on the PC screen.

Click "Snooze" and select "2 Months" to hide it for 2 months. Repeat the "Snooze" every 2 months to get rid of the message.


Scenario 2

1



When you install the cartridge, the printer displays "Ready". The cartridge chip is recycled and it will show  icon, but it will NOT affect printing, so you can start to print.

2



When request printing from a PC, it will prompt above message on the PC screen.

Click "Snooze" and select "2 Months" to hide it for 2 months. Repeat the "Snooze" every 2 months to get rid of the message.




When the printing turns light, it means the toner cartridge is about to run out and you need to replace. We reuse the original HP chips with the aim of creating eco-friendly toner cartridges and reducing electronics pollution.


Product Instruction UK


The following steps for printers above:


Scenario 1



When the first time you install the cartridge, your printer will pop up the above message. Press the "OK" button to continue.




The printer then shows  icon, as the cartridge chip is recycled. However, it will NOT affect printing. The printer is still ready, so you can start to print.





When request printing from a PC, it will prompt above message on the PC screen.

Click "Snooze" and select "2 Months" to hide it for 2 months. Repeat the "Snooze" every 2 months to get rid of the message.

Scenario 2



When you install the cartridge, the printer displays  icon, as the cartridge chip is recycled. However, it will NOT affect printing. The printer is still ready, so you can start to print.



When request printing from a PC, it will prompt above message on the PC screen.

Click "Snooze" and select "2 Months" to hide it for 2 months. Repeat the "Snooze" every 2 months to get rid of the message.



When the printing turns light, it means the toner cartridge is about to run out and you need to replace. We reuse the original HP chips with the aim of creating eco-friendly toner cartridges and reducing electronics pollution.