


## BUTTON FUNCTIONS AND LED INDICATORS



### 1 Volume Control Knob



Turn the knob left / right to decrease / increase playback's, microphone's or Audio Balance's volume. Press and hold to initiate *Bluetooth®* Pairing\*.

\**Bluetooth* connection is reserved for device control and Super X-Fi profile upload only. Audio streaming is not available via *Bluetooth*

<b>BLUE</b>	Playback Volume
<b>RED</b>	Microphone Volume
<b>GREEN / ORANGE / CYAN</b>	Audio Balance
<b>WHITE</b>	<i>Bluetooth</i> Low Energy (BLE) Connection

### 2 Microphone Control Button



AUDIO BAL

Press once to switch to Mic control. Use Volume Control Knob to control Mic Input Level. Press the Volume Control Knob once to mute Mic. Press and hold to activate / deactivate Audio Balance.

<b>LED OFF</b>	Mic Input – Off
<b>RED</b>	Mic Input – On
<b>GREEN</b>	Audio Balance – On

### 3 Audio Balance



Press and hold the Microphone Control Button to enable / disable Audio Balance\*. Turn the knob clockwise to increase your game's audio level while reducing chat's volume audio. Turn the knob counter-clockwise to increase your chat's volume level while reducing the game's audio level. Press the Volume Control Knob once to reset the balance.

\*Audio Balance is available on PC, Mac, PS5, and PS4 only. A HDMI to Optical converter (not included) is required to access Audio Balance on the PS5.

**GREEN**

Audio Balance – On

**ORANGE**

Audio Source – Sound Blaster X4's SPDIF-out endpoint

**CYAN**

Audio Source – Sound Blaster X4's speakers endpoint

### 4 Mode Button



Press to cycle through EQ modes. When Super X-Fi is disabled, users may select from three different EQ modes by pressing the Mode button. When Super X-Fi is enabled, only EQ for SXFI mode is available.

You may also customize and assign their own EQs to any of the EQ modes on the Creative app to better suit your preference.

**LED OFF**

EQ – Off

**GREEN**

EQ for SXFI\*

\*Only available when Super X-Fi is enabled

**WHITE**

Mode 1 – Music

**PURPLE**

Mode 2 – Movies

**BLUE**

Mode 3 – Footsteps Enhancer

**ORANGE**

Direct Mode (Press and hold)

### 5 Super X-Fi Button



Press and hold to switch between Line-out (Speaker) and Headphones-out. While in Headphones mode, press once to enable / disable Super X-Fi.

Set up your Super X-Fi profile by following the instructions provided under "Setting Up Super X-Fi".

**LED OFF**

Line-out (Speaker)

**GREEN**

Headphones-out: Super X-Fi – On

**BLUE**

Headphones-out: SXFI BATTLE Mode – On

**ORANGE**

Headphones-out: Super X-Fi – Off