

70X70mm



AS-172  
使用指南

产品规格：

1. 产品型号：AS-172

2. 产品配对名：AS-172

3. 声道系统：无线立体声

4. 控制方式：触控

5. 耳机播放时长：约4小时

6. 蓝牙有效距离：≥10米

7. 耳机功放类型：内置芯片

充电仓电池参数

1. 充电仓充电口：Type-c

3. 充电仓输出电压：5V±0.2V

5. 充电仓电池容量：200MAH

7. 充电仓有线充电时长：≤1.5H

2. 充电仓输入电压电流：5V200MA

4. 耳机电池容量：30MAH

6. 充电仓有线充电电流：200±20MAH

8. 仓过放保护：有3.1V

功能说明：

1. 开机：①取出耳机自动开机②连接前长按2s开机

2. 关机：①把耳机放入充电仓关机充电②连接前长按5s关机③未连接手机时，五分钟后自动关机

3.TWS配对成功:当左右耳机开机后,左右耳机立即进行互配,配对成功后,进入配对模式

4.蓝牙已连接:①耳机进入配对状态,手机搜索到蓝牙配对名,点击连接即可②已连接过蓝牙设备,开机后左右耳机自动回连,主机自动回连到最后一台连接过的设备,回连不成功耳机进入配对状态,会提示“蓝牙已连接”

5.蓝牙已断开:①手动关闭手机蓝牙端,耳机进入配对模式②耳机与手机超距后断开,5分钟内回到有效距离范围,能正常回连手机,超过5分钟会自动关机,会提示“蓝牙断开”

6.暂停/播放:单击任意耳机音乐暂停

7.上/下一曲:双击任意耳机上下歌曲

8.加/减音量:三击任意耳机切换音量加減

9.语音助手:长按2s任意耳机;会提示“咚”

10.来电:对方打电话来;会有“系统提示音”

11.接听:单击任意耳机

12.挂断:单击任意耳机

13.拒接:长按任意耳机MFB键;

14.电池电量低: 20%时电量时, 5分钟提示一次;会提示“电池电量低”;

15.耳机充电中:耳机红灯亮, 充电仓白灯亮

16.耳机充满电:耳机红灯灭, 充电仓白灯灭

17.充电仓充电中:橙灯慢闪

18.充电仓充满电:橙灯常亮

19.游戏模式:长按5s任意耳机MFB键,会有“语音提示”

温馨提示

1) 耳机充电过程中, 耳机处于关机状态, 会断开与手机的连接, 电源适配器必须选用5V±0.2V

2) 耳机开机后, 如果手机未搜索到耳机, 可以先关闭手机蓝牙再重新打开手机蓝牙, 手机会重新索

3) 当耳机一边无声时, 请检查充电仓和耳机底部充电端子是否有脏污, 如有脏请使用棉签进清洁或可将左右耳重新放入充电仓充电约5S后再取出, 待左右耳组队成功后再次连接手机

注意事项:

1. 切勿使用具有腐蚀性的清洁剂清洁本产品。

2. 切勿让本产品加热或靠近火源。

3. 切勿让本产品长时间受阳光直接照射。

4. 切勿将本产品弃置于火中, 避免发生爆炸。

5. 切勿尝试拆出本产品做任何修改。

6. 如长时间不使用本产品, 请将它储存于干燥的环境中, 并每月至少为耳机充电一次以延长寿命, 避免极端的温度和灰尘。

保修卡/合格证

请您妥善保管好保修证和购机凭证。 这些将是您的保修凭证。

产品保修单(非人为损坏保修一年)

用户姓名		联系电话	
产品编号		购机日期	
通讯地址			
故障描述			

检修记录

序号	日期	检修记录	修理人员
1			
2			
3			

合格证

生产日期: \_\_\_\_\_  
检验员: \_\_\_\_\_

adol



AS-172  
User Guide

Product specifications:

1. Product model: AS-172

2. Product pairing name: AS-172

3. Track system: wireless stereo

4. Control mode: Touch

5. Headset playing time: about 4 hours

6. Bluetooth effective distance: ≥10 m

7. Headset power amplifier type: built-in chip

Charging compartment battery parameters

1. Charging bay Charging port :Type-c

3. Charging bin output voltage: 5V±0.2V

5. Charging bin battery capacity :200MAH

7. Wired charging time of charging bin :≤1.5 H

2. Input voltage and current of charging bin: 5V200MA

4. Headset battery capacity: 30MAH

6. Charging current of charging bin: 200±20MAH

8. Over-discharge protection: 3.1V

Function description:

1. Power on: ① Take out the earphone to power on automatically ② long press 2s before connection

2. Power off: ① Put the earphone into the charging bin to power off and charge it ② long press 5s before connection to power off ③ when the phone is not connected, it will automatically power off after five minutes

3. TWS pairing is successful: when the left and right earphones are powered on, the left and right earphones will be paired with each other immediately.

After the pairing is successful, enter the pairing mode

4. Bluetooth is connected: O headset enters the pairing state, the mobile phone finds the Bluetooth pairing name, click to connect 2) has connected to the Bluetooth device, after turning on the left and right earphones automatically connect back to the host and automatically connect to the last connected one If the device fails to connect back, the headset enters the pairing state, and it will prompt "Bluetooth connected"

5. Bluetooth has been disconnected: O Manually turn off the Bluetooth end of the mobile phone, and the headset enters pairing mode. 2 The headset is disconnected from the mobile phone after being out of range. It will return to the effective distance range within 5 minutes, and it can be connected to the mobile phone normally. After 5 minutes, it will automatically shut down. It will prompt "Bluetooth disconnected" 6. Pause/Play: Click any earphone music to listen

7. Up and down song: Double-click any earphone to up and down songs 8. Add volume: Triple-click any earphone to switch volume addition and subtraction

9. Voice assistant: Long press 2s any headset: will prompt "Dong"

10. Incoming call: The other party is calling; there will be a "system prompt tone"

11. Answer: Click any headset

12. Hang up: click any headset

13. Rejection: long press any headset MFB button:

14. Low battery power: When the battery power is 20% hours, it will prompt "battery power low" once every 5 minutes:

15. Earphone charging: the red light of the earphone is long, and the white light of the charging compartment is long

16. Fully charged earphones: the red light of the earphones is off, and the white light of the charging compartment is off.

17. Charging in the charging compartment: the orange light flashes slowly

18. The charging compartment is fully charged: the orange light is always on

19. Game mode: press and hold any headset MFB button for 5s, there will be a "voice prompt"

Kind tips

1) During the charging process of the earphone, the earphone is turned off and will be disconnected from the mobile phone. The power adapter must be 5V ± 02V

2) After the headset is turned on, if the mobile phone does not search for the headset, you can turn off the Bluetooth of the mobile phone and then turn on the Bluetooth of the mobile phone, and the mobile phone will search again.

3) When the earphones are silent on one side, please check whether the charging compartment and the charging terminals at the bottom of the earphones are dirty. If they are dirty, use a cotton swab to clean them or put the left and right ears back into the charging compartment for about 5

Precautions:

1. Do not use corrosive cleaning agents to clean this product.

2. Do not let this product be heated or near a fire source.

3. Do not expose this product to direct sunlight for a long time.

4. Do not dispose of this product in fire to avoid explosion.

5. Do not try to disassemble the product for any modification.

6. If you do not use this product for a long time, please store it in a dry environment, and charge the headset at least once a month to prolong the life, avoid extreme temperature and dust.

Warranty card/certificate of conformity

Please keep the warranty certificate and purchase voucher properly, these will be your warranty certificates.

Product warranty (one year warranty for non-human damage)

User name		Contact number	
Product number		Date of purchase	
Mailing address			
Fault description			

Maintenance records

serial number	date	Maintenance records	Repair staff
1			
2			
3			

Certificate

date of modification: \_\_\_\_\_  
inspector: \_\_\_\_\_

adol

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.