





connectivity


Xbox One / Xbox Series X / Xbox Series S

- Connect the controller to your Xbox One and Xbox Series X/S via its USB cable. Status LED is on when the controller is successfully connected



Windows 10

- Connect the controller to your Windows device via its USB cable. Status LED is on when the controller is successfully connected



- Required system: Windows 10 or above


button swap

1. press and hold any two of **A/B/X/Y/LB/RB/LSB/RSB** buttons you would like to swap
 2. press the **star** button to swap them,profile LED blinks to indicate the success of the action
 3. press and hold any of the two buttons which have been swapped and press the **star** button to cancel it
- button mapping goes back to its default mode when controller is turned off
 - please visit support.8bitdo.com for further information and assistance

volume control


1

- Press and hold **profile + up/down** to turn up/down in-game volume



2

- Press and hold **profile + left/right** to adjust the balance between voice chat and game volume




8BitDo Ultimate Software

- button mapping, thumb stick sensitivity adjustment & trigger sensitivity alteration
press **profile** button to activate/deactivate the customization. LED turns on to indicate the activation
- e.g. set P1/P2 buttons as L3/R3 and more
 - available on Xbox/Windows 10/Android/iOS
 - please visit Microsoft Store, App Store, Google Play or support.8bitdo.com to download the software

support




- please visit support.8bitdo.com for further information & additional support



连接


Xbox One / Xbox Series X / Xbox Series S 主机

- 将手柄连接至 Xbox 主机的 USB 端口, 状态指示灯常亮即可使用



Windows 10 设备

- 将手柄连接至 Windows 10 设备的 USB 端口, 状态指示灯常亮即可使用



- 低于 Windows 10 版本的设备不支持


快速按键映射

1. 按住 A、B、X、Y、左肩键、右肩键、左摇杆按键、右摇杆按键任意两个按键, 并按下 [星号键] 即可快速交换按键功能。
 2. 按住任意切换过的按键, 再按下 [星号键] 可恢复默认功能。
 3. 设置过切换的按键, 按下时配置指示灯会闪烁。
- 交换按键不会保存, 关机重启后恢复默认。

声音调节


1

- 按住配置键 + 十字键上、下可提高、降低主音量



2

- 按住配置键 + 十字键左、右可调节语音、游戏之间的音量平衡



自定义配置

- 可在 Xbox 主机, Windows 10, 安卓和 iOS 上使用八位堂精英软件。
- 可对手柄按键映射、摇杆灵敏度、扳机键灵敏度、振动强度等功能进行自定义配置。
- 从 App Store, Microsoft Store 或 support.8bitdo.cn 下载安装“八位堂精英软件”。
- 轻按 [配置键] 可开启 / 关闭自定义配置, 使用自定义配置时, 配置指示灯会亮起。
- 如P1,P2可设置为L3,R3或其他功能按键。

技术支持



- 请访问 support.8bitdo.cn 了解详细信息。