


REPLACEMENT PARTS - MODEL 316.795861

2-CYCLE TRIMMER




Item	Part No.	Description
1	753-06282	Rear Cover Assembly (includes 2 & 3)
2	791-181862	Starter Screw
3	753-06244	Starter Assembly Guard (includes 2)
4	753-06245	Rear Engine Cover (includes 5)
5	791-181345	Cover Screw
6	753-06104	Adapter
7	753-06091	Pawl Assembly
8	753-06499	Flywheel Assembly
9	753-06247	Washer
10	753-06248	Spacer
11	753-05860	Clutch Assembly
12	753-06285	Clutch Cover Assembly (includes 2, 13-15 & 21)
13	791-182519	Anti-Rotation Screw
14	753-04003	Clamp Screw
15	791-180217	Clamp Nut
16	753-06418	Muffler Assembly (includes 17 & 35)
17	753-06419	Muffler Gasket
18	753-06250	Fuel Tank Assembly (includes 19 & 20)

Item	Part No.	Description
19	791-181930	Tank Screw
20	753-05057	Fuel Cap
21	791-182366	U-Shaped Nut
22	753-05877	Lead Wires
23	753-06570	Throttle Cable
24	753-06303	Module Assembly
25	753-06440	Cylinder Gasket
26	753-05703	Cylinder Bolt
27	753-06193	Spark Plug
28	753-06189	Insulator Assembly (includes 29 & 30)
29	753-06184	Insulator O-Ring
30	753-06185	Carburetor O-Ring
31	753-06288	Carburetor
32	753-06253	Carburetor Gasket
33	753-06500	Aircleaner Assembly (includes 34)
34	753-06417	Aircleaner Filter
35	753-06294	Muffler Screw
36	753-06501	Short Block Assembly (includes Crankcase, Cylinder, Piston, 8-10 & 24-27)

REPLACEMENT PARTS - MODEL 316.795861


2-CYCLE TRIMMER



Item	Part No.	Description
1	753-05192	Throttle Housing Assembly (includes 2-5)
2	753-05517	Throttle Trigger
3	753-05007	Spring
4	753-05171	Throttle Lock-out
5	791-182405	Switch
6	791-610327	Shoulder Strap Clip
7	753-04236	Upper Drive Shaft Housing Assembly
8	753-05008	D-Handle Assembly (includes 9 & 10)
9	753-05295	Barrier Bar Assembly
10	791-181070	Screw
11	753-06139	Lower Drive Shaft Housing Assembly
12	753-06292	Shield Assembly (includes 13 & 14)
13	753-06126	Blade Assembly
14	753-06125	Screw
15	791-182519	Anti-Rotation Screw
16	791-182193	Gear Box (includes 15, 17 & 25)
17	791-182196	Gear Box Spacer
18	753-05489	Cutting Head Assembly (includes 26)
19	753-1190	Split Boom Coupler (includes 20-23)
20	791-182057	Screw
21	791-181617	Bolt
22	791-181981	Adjustment Knob
23	753-04386	Knob Retaining Nut
24	753-05267	Lower Flexible Drive Shaft
25	791-182195	Gear Box Screw
26	753-05036	Cutting Head Cap
*	753-05038	Tube of Line

* Items Not Shown

REPLACEMENT PARTS - MODEL 316.795861 2-CYCLE TRIMMER



Item	Part No.	Description
1	791-160226	Lower Drive Shaft Housing Assembly (includes 2)
2	753-05267	Lower Flexible Drive Shaft
3	791-182200	Shield Mount Screw Assembly
4	791-182193	2-Piece Gear Box Assembly (includes 5-8)
5	791-182195	Gear Box Mounting Hardware
6	791-182519	Anti-Rotation Screw
7	791-182196	Blade Driver
8	753-04348	Palnut
9	791-147492	Blade Shield/Shield Mount
10	791-145873B	4-Tooth Blade
11	791-147490	Retaining Washer
12	791-181699	Nut
*	791-180014B	Blade Retaining Kit (includes 11 & 12)
*	791-613226	Locking Rod Tool
*	791-682075B	Shoulder Harness
*	791-612605	Hanger

* Items Not Shown