



Volume
Volumen



Windows Hello camera
Caméra Windows Hello
Cámara de Windows Hello



Surface Connect port
Port Surface Connect
Puerto Surface Connect



Power button
Bouton d'alimentation
Botón de encendido



Studio Mics
Micros de studio
Micrófonos de estudio




Front-facing camera
Caméra à l'avant
Cámara frontal



USB-C Thunderbolt™4
Charging capable
Capacité de rechargement
Compatible con carga



NFC reader
Lector NFC
Lector de NFC



support.microsoft.com

 windows.com/accessibility

 surface.com/repairability



M1294623-001

©/TM/®2024 Microsoft
Model 2079