

/110/119/111



H1x16



H9x2



H2x16



H10x2



H3x4



±±



H4x12



H5x2




H6x1





H7x1








H8x4



F1 F2










⊕⊕



D



H1x12



H7x2




H8x1




H5x1


Step 1: ①



Step 3: ③



Step 2: ②



How to adjust hinges on the doors

1. To adjust door forward or backward.
2. To adjust door to right or to left.
3. To adjust door up or down

