ADMESS


Ultra-thin Scissors Foot Backlit Office Keyboard

User Manual


All Seenda products come with a 12-months warranty policy, please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience.

Our email: **support@seenda.com**Our website: **www.seenda.com**

Overview




BT1 Indicator




Bluetooth Connection

1 Turn on the power switch.



2 Long press the Fn + 91 / 92 / 93 3 seconds, The blue light flashes to enter the code matching state.




Windows 10 System


3 Click "Bluetooth Devices".



4 Click "Add or Remove Bluetooth Devices".



5 Your computer will automatically search for "Bluetooth 5.1 Keyboard" and then click "pair".



6 "Bluetooth 5.1 Keyboard" is connected and it can be used normally.




Mac OS System

Please complete the Bluetooth connection step (1)(2) before pairing.


3 Click "System Preferences" on Mac.



4 Click "Bluetooth" in "System Preferences".



S Your computer will automatically find "Bluetooth 5.1 Keyboard", then click "pair", and you can use it after installation.



iOS System

Please complete the Bluetooth connection step (1)(2) before pairing.


3 Click "Settings" on the device and then turn on Bluetooth.



4 Your computer will automatically find "Bluetooth 5.1 Keyboard", then click "pair", complete pairing.



5 "Bluetooth 5.1 Keyboard" is connected and it can be used normally.




Android System

Please complete the Bluetooth connection step ①② before pairing.

3 Click "Settings" on the device and then turn on Bluetooth.



4 Your computer will automatically find "Bluetooth 5.1 Keyboard", then click "pair", complete pairing.



6 "Bluetooth 5.1 Keyboard" is connected and it can be used normally.



Keys and Function

| Key | iOS/Android/Mac | Windows |
|-----|-------------------------------|-------------------------------|
| * | Brightness Down | Brightness Down |
| * | Brightness Up | Brightness Up |
| 80 | Open the task browsing window | Open the task browsing window |
| Q | Search | Search |
| М | Previous | Previous |
| DII | Play/Pause | Play/Pause |
| DI | Next Track | Next Track |
| ٩× | Mute | Mute |
| ą, | Volume - | Volume - |
| d») | Volume + | Volume + |
| 0 | Screenshot | Screenshot |
| 4 | Lock | Lock |
| △ | Return to Desk | Home Page |

Notice: You need to press "FN" key first before you use the multimedia functions.

Specifications

| System support | Win XP/7/8/10/11, Mac OSx10.4 or above. |
|------------------|---|
| Distance | 10m |
| Battery capacity | 180mAh |
| Working voltage | 3.7V |
| Working current | 10mA |
| Standby current | <1mA |
| Sleeping current | <20 uA |
| Key stroke life | Over 8 million |
| Size | 342x116x10.95mm(open) 181.5x116x19mm(folding) |
| Weight | 255g |

Package Includes

- ▶ Wireless Keyboard
- ► Type C Charging Cable
- User Manual