

- \* 开机:按下 **home** 键。
- \* 关机:按住 **home** 键 3 秒。
- \* 强制关机:按住 **home** 键 8 秒。

Switch



- \* 要求 Switch 主机系统版本为 3.0.0 或更高版本。
- \* 不支持 NFC 扫描、红外摄像头、HD 振动、通知灯等功能。

蓝牙连接

1. 按下 **home** 键 开启手柄。
2. 按住 **配对键** 约 3 秒至 **状态指示灯** 快速闪烁，进入配对状态。(仅首次连接时需要配对)
3. 打开 Switch 主机“手柄”选项，选择“更改握法 / 顺序”，等待手柄连接。
4. 连接完成后，**状态指示灯** 常亮。

有线连接

- \* 请确保 **设置 - 手柄与感应器 - Pro 手柄的有线连接** 功能已开启。
- 使用 USB 线将手柄连接到 Switch 主机的 USB 端口，等待系统识别完成后即可使用。

电源



配备 480mAh 可充电式锂电池，可持续使用约 16 小时，充电时间约 2 小时。

电源状态		电源指示灯状态
电量不足	→	红灯闪烁
正在充电	→	红灯常亮
充电完成	→	红灯熄灭

- \* 开机后 1 分钟内未连接，或连接后 15 分钟内无操作会自动关机。
- \* 使用有线连接时手柄不会自动关机。

安全警示




- \* 请使用制造商的电池、充电器、配件。
- \* 在用户使用第三方的配件时，制造商不能对用户的安全负责。
- \* 请勿自行拆卸、改装或修理设备。
- \* 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- \* 对设备的任意变动或改装，将导致制造商对设备不予保修。

技术支持



- \* 请访问 [support.8bitdo.cn](https://support.8bitdo.cn) 了解详细信息。



- \* Press the **home button** to turn on the controller.
- \* Hold the **home button** for 3 seconds to turn off the controller.
- \* Hold the **home button** for 8 seconds to force the controller off.

Switch



- \* System requirement: Switch 3.0.0 or above.
- \* NFC scanning, IR camera, HD rumble, and notification LED are not supported.

Bluetooth connection

1. Press the **home button** to turn on the controller.
2. Hold the **pairing button** for 3 seconds to enter its pairing mode,the **status LED** will start to blink rapidly.  
(This is required for the very first time only)
3. Go to your Switch settings--Controllers and Sensors--Change grip/order, then wait for the connection.
4. The **status LED** will remain solid when the connection is successful.

Wired connection

- \* Please ensure the [**Pro Controller Wired Communication**] is enabled in the system setting.
- Connect the controller to the Switch via a USB cable and wait until the controller is recognized by the system to play.

Battery



16 hours of play time with a 480 mAh built-in lithium battery pack, rechargeable with 2 hours charging time.

status -		LED indicator -
low battery	→	red LED blinks
battery charging	→	red LED stays solid
battery full charged	→	red LED turns off

- \* The controller will automatically shut down if there is no connection within 1 minute after startup or no activity within 15 minutes after connection.
- \* The controller will not shut down when it's over wired connection.

Safety Warnings



- \* Please always use batteries, chargers, and accessories provided by the manufacturer.
- \* The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- \* Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- \* Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- \* Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

Support



Please visit [support.8bitdo.com](https://support.8bitdo.com) for further information & additional support.

