



www.sv3c.com

# INSTRUCTIONS FOR HOW TO SET PTZ COMMANDS

## All PTZ Commands

| Routes                                     | Control method                                  |
|--------------------------------------------|-------------------------------------------------|
| Set auto human motion tracking command     | Enter presetting number 92 and submit to set-up |
| Activate human tracking command            | Call presetting number 92                       |
| Disable auto human tracking function       | Call presetting number 94                       |
| The first cruise route(presetting 1-16)    | Call presetting number 41                       |
| The second cruise route (presetting 17-32) | Call presetting number 42                       |
| Enable Scan left and right limitation      | Call presetting number 38                       |
| Cruise stop over presetting for 2 seconds  | Set presetting number 51                        |
| Cruise stop over presetting for 4 seconds  | Set presetting number 52                        |
| Cruise stop over presetting for 6 seconds  | Set presetting number 53                        |
| Cruise stop over presetting for 8 seconds  | Set presetting number 54                        |
| Cruise stop over presetting for 10 seconds | Set presetting number 55                        |
| Clear left and right limitation Scan       | Set presetting number 38                        |
| Set left limitation                        | Set presetting number 36                        |
| Set right limitation                       | Set presetting number 35                        |
| Restore factory setting                    | Set presetting number 40                        |

### Please note:

Before activating the auto tracking function, please ensure that you have set-up the auto human tracking function command number 92 for your camera using either the app or browser.


# How to turn on smart tracking

Turn on tracking function : Call / Transfer preset 92

Turn off tracking function : Call / Transfer preset 94

## Set on App CamhiPro

1. Turn on: preset position input 92 and click Transfer/ Call, as below



2. Turn Off: preset position input 92 and click Transfer/ Call to active