One NZ Deco X50 Modem Quick Start Guide

Your modem's here and getting set up is easy.

1 Plug your X50 modem into power.

2 Plug the supplied ethernet cable into the first port on your X50 modem and plug the other end into the ONT (fibre wall box) – this is the unit your local fibre company would have installed in your home, which is connected to the fibre optic cables in the street.

3 The light on the side of your modem will flash yellow while it's starting up, flash blue during set up, and will turn solid green once it's connected to fibre.

4 You can now connect your devices to WiFi using the username SSID and password on the base of your X50 modem OR simply hover your phone camera over the QR code to connect.

TIP To add more Deco units, manage your network, prioritise devices and heaps more, download the Deco app and follow the prompts. Make sure you select the X50 as your modem type in the app.

Download on the **App Store** · GET IT ON **Google Play**

Need help setting up?
Call us on 0800 800 966.