

ATTENTION

Before you start using the product, please remove any protective foil from the baby unit.

Specifications

Range:

up to 50 meters indoors
up to 300 meters outdoors

Baby unit power:

5V DC 1A power adaptor (incl.)
Model: VT05EEU05100
Frequency: 2405-2475 MHz
Modulation: FSK
RF-power: <20 dBm

Important safety instructions

The applied nameplate is located at the bottom of the baby unit's base.

- CAUTION:** Do not install the baby unit at a height above 2 metres.
- Use and store the product at a temperature between 0°C and 40°C.


Declaration of conformity

Hereby, Commaxx declares that the radio equipment type Alecto DVM2043C is in compliance with directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following Internet address: https://commaxx-certificates.com/doc/DVM2043C_doc
Use of this equipment is allowed in all countries of the EU. In France, Italy, Russia and Ukraine, only indoor use is allowed.

Information power adaptor baby unit:
Manufacturers name and address:
Vtech Telecommunications LTD, 23/F.,
Tai Ping Industrial Centre, Block 1, 57 Ting Kok Road,
Tai Po, Hong Kong.
Model Identifier: VT05EEU05100
Input voltage: 100 - 240V~
Input AC frequency: 50/60 Hz
Output voltage: 5.0V DC
Output current: 1A
Output power: 5.0 W
Average active efficiency: 74.0 %
Efficiency at low 10% load: -
No load power consumption: 0.07 W



OVERVIEW - BABY UNIT




- | | |
|--|--|
| 1 Light sensor | 8 Night light on/off key |
| 2 Camera | 9 Antena |
| 3 Infrared LEDs | 10 Temperature sensor |
| 4 Night light | 11 Power jack |
| 5 Microphone | 12 PAIR key |
| 6 Speaker | • Press and hold for 3 seconds to enter pairing mode. |
| 7 POWER LED light | 13 Slots for wall mounting |
| • On when the baby unit is turned on and is paired to the parent unit. | |
| • Flashes when the link to the parent unit has lost. | |

1 CONNECT AND POWER ON THE BABY UNIT

NOTES

- Use only the power adaptor supplied with this product.
- Make sure the the baby unit are not connected to an electronically/timer controlled electric power outlet.
- Connect the power adaptor in a vertical or floor mount position only. The adaptor prongs are not designed to hold the weight of the baby unit. Otherwise, the adaptor may not properly connect to the outlets.
- Make sure the the baby unit and the power adaptor cords are out of reach of children.

Connect the power adaptor to the baby unit and a power supply to power on the unit.
Disconnect the baby unit from the power supply to power off.



2 BEFORE USE

Pair a new baby unit


Each newly purchased baby unit (**DVM2043C**) must be paired to your system (**DVM2043**).

NOTES


- You can pair an additional baby unit to your parent unit. New baby unit must be paired to the parent unit before use.
- Make sure you power on the parent unit before pairing.

- Turn on your parent unit and baby unit.
- Press **≡** when the parent unit is idle.
- Go to **⚙** > **⊕**, select **2**.
If you have more baby units: select **⊕**, then select **2**, **3** or **4**.
- Press and hold** the **PAIR** button for 3 seconds until you hear a "beep".
- When the baby unit is successfully paired with your parent unit, the parent unit displays **✓** and the live video.

3 POSITIONING THE BABY MONITOR



WHAT'S IN THE BOX




MOUNT THE BABY UNIT ON DRY WALL (OPTIONAL)



NOTES

- Check for reception strength and camera angle before drilling the holes.
- The types of screws and wall plugs you need depend on the composition of the wall. You may need to purchase the screws and wall plugs separately to mount your camera units.

1. Place the wall mount bracket on a wall and then use a pencil to mark two holes in parallel. Remove the wall mount bracket and drill two holes in the wall (5.5mm drill bit).




2. If you drill the holes into a stud, go to step 3.


- If you drill the holes into an object other than a stud, insert the wall plugs into the holes. Tap gently on the ends with a hammer until the wall plugs are flush with the wall.



3. Align the wall mount bracket and screws with the holes in the wall as shown. Tighten the screw in the middle hole first, so that the wall mount bracket position is fixed. You can tighten the other screw in the top hole.




4. Place the camera unit on the wall mount bracket, and then slide it forward until it locks into place. Connect the power adaptor to the camera unit and a power supply.




OR

3. Insert the screws into the holes and tighten the screws until only 6.5mm of the screws are exposed.




4. Place the camera unit on the wall mount bracket, and then slide it forward until it locks into place. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it locks into place.

1




2



5. You can maximise your camera unit viewing angle by tilting the wall mount bracket.

Hold the camera unit, and then rotate the knob in an anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your camera unit up or down to adjust to your preferred angle. Then, rotate the knob in a clockwise direction to tighten the joint and secure the angle.



TIPS AND REMARKS

INTERFERENCE-FREE:

This baby display monitor is digitally coded. This means you will never receive signals from other devices, nor can the signal from your baby unit(s) be received by e.g. your neighbors.

In case the baby unit(s) or parent unit is placed in or in the close vicinity of electromagnetic fields, the signal (images or sound) can be slightly affected. If this happens, try a different location for the baby unit(s) or parent unit or move, if possible, the source of the interference.

EAVESDROPPING/WIRETAPPING:

Eavesdropping/wiretapping of the signals from this baby video monitor is nearly impossible. Not only must one be within range of the baby video monitor, one also needs some very costly equipment.

MAINTENANCE:

Only clean the baby monitor with a moist cloth; never use chemical cleaners. Before any cleaning, you must disconnect the adaptors.

RANGE:

The baby display monitor has a range of up to 300 meters in an open field and up to 50 meters indoors; this range depends on local circumstances.

DELAY IN IMAGES AND SOUND:

The baby unit transmits the images and sound to the parent unit in digital blocks. The parent unit converts these signals back to a recognizable image and a comprehensible sound. Therefore, there is a small delay between the moment of movement and making sounds and the display and sounds of the parent unit.

Besides that, the sounds and images on the parent unit are not exactly simultaneous.



Commaxx BV
Wiebachstraat 37
6466 NG Kerkrade
The Netherlands

www.alectobaby.com