

Owner Manual

Materials: Kiln-dried mango wood top, low-sheen clear seal.

Daily Care

- Dust with a dry microfiber cloth.
- Blot spills immediately with a slightly damp cloth; follow with a dry wipe.

Deep Cleaning – Monthly

- Use a pH-neutral wood cleaner (no ammonia, bleach, or silicone).
- Avoid abrasive pads; always wipe along the grain.

Protection & Placement

- Use coasters, place mats, and felt pads under decor.
- Keep 2 in (5 cm) away from active HVAC vents & radiators.
- Maintain indoor RH 35–55 % to minimise warping.

Finish Refresh – Every 6 months

- Apply a thin coat of beeswax-based furniture polish; buff lightly after 30 min.

Hardware Check

- Re-tighten leg bolts 30 days after assembly, then every 6 months.

Avoid ✗ Standing liquids >15 min ✗ Direct heat >140 °F ✗ Harsh chemicals or steam mops ✗ Dragging when moving