


Handing selection XS4 Original+



- (Eng) **Handing selection**
 (E) Selección mano
 (D) Drückerichtung wählen
 (F) Choisir le sens de la bêteuille
 (I) Scegliere il verso
 (P) Selezione mão


Key
override

CLICK
HERE




E i 4xx.. RO series
 E i 4xx.. SH series


1




2



3



4



5

