

# Garden Shed Use and Care Manual

## Assembly Precautions

- **Read the Manual First:** Before starting the assembly of your garden shed, it is crucial to read the assemble manual in advance. The manual contains detailed step - by - step instructions that will guide you through the entire process. Make sure you understand all the steps and have all the necessary tools and parts ready.
- **Avoid Over - tightening:** When tightening nuts during the assembly, be extremely careful not to over - tighten them. Over - tightening can cause the parts to distort or even break. Follow the recommended torque settings provided in the manual. If no specific settings are given, use a reasonable amount of force. Tighten the nuts just enough to ensure a secure fit without applying excessive pressure.

## Usage Considerations

- **Color Variation:** Please be aware that the actual color of the garden shed may slightly differ from the photo you saw. This is mainly due to lighting conditions during photography and the display settings of your monitor. The difference is normal and does not affect the quality or functionality of the product. So, do not be alarmed if the shed appears a bit different in person.

- **Size Tolerance :** The dimensions of the garden shed are obtained through manual measurement. As a result, there may be some reasonable error. The overall size is specified as 36.6x21.9x63 inches (length x width x height), and each shelf has a weight capacity of 33 lbs. However, minor deviations in size are to be expected. This does not mean there is a defect in the product, and it should not cause any significant issues during use.

## **Care and Maintenance**

- **Weather - resistant Features :** The garden shed is designed to be weather - resistant. The asphalt waterproof roof protects against rain, snow, and sunlight. Regularly check the roof for any signs of damage, such as cracks or holes. If you notice any issues, contact customer service for guidance on repair. The polycarbonate panels are durable and provide good insulation. Keep them clean by gently wiping them with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could scratch the panels.
- **Storage and Organization :** The shed comes with four adjustable shelves, two of which are foldable. Use these shelves to organize your gardening tools, plants, or other items. When storing items, make sure not to exceed the weight capacity of each shelf. The adjustable foot pads help the shed adapt to uneven ground. If you need to move the shed to a different location, ensure that the foot pads are adjusted properly for stability.

- **Security Features:** The lockable doors and anti - tipping devices are in place to keep your items safe. Regularly check the locks to ensure they are working properly. If you find any problems with the locking mechanism, contact customer service. Also, make sure the anti - tipping devices are securely attached and functioning as intended.

. **After - sales Service**

- **Contact Information:** If you have any questions, concerns, or issues regarding the garden shed, whether it's during assembly, use, or maintenance, please feel free to contact our customer service. We are here to assist you and will do our best to resolve your problems promptly.
- **Natural Knots in Wood:** Remember that natural knots in the wood are a normal characteristic and do not constitute a reason for return. These knots are a natural part of the wood's structure and do not affect the integrity or performance of the shed.

By following these use and care instructions, you can ensure that your garden shed serves you well for a long time and provides a functional and efficient space for your gardening and storage needs.