




NC9 Plus ACTIVE NOISE CANCELLATION User Manual

1.0 Product diagrammatic sketch



2.0 Wearing diagrammatic sketch



3.0 Wearing Steps

Step

Step1: Ensure

Ensure sounds hole downward, then place earbuds into ear. $\label{eq:control}$

Step2:

Rotate earbud back to auricle side to fit snugly.







Sound hole upward is a incorrect way to wear the earbuds.

4.0 Operation of earbuds

4.1 How to pair

- 1. Open the charging case, they will power on automatically and will connect to each other automatically within 10 seconds.
- 2. The two earbuds flash red and blue alternately. (Pairing Mode)
- 3. Search for pairing name [TOZO-NC9 Plus] and select it.



4.2 Another method of turning one & Turing off

Turn on: Tap and hold the Touch Control on borh earbuds for over 3 seconds.

Turn off: 1. Touch the Control button 5 seconds will turn off when earbuds in playless status.

2. The earbuds will turn off automatically after it is disconnected for more than 5 minutes. (Normal mode)

4.3 Reset

If you accidentally get only one earbud work, or fails to pair earch other, please reset it:

- Delete all TOZO-NC9 Plus records on the phone, then turn off the Bluetooth. Take earbuds out from the charging case, press the touch panel for 5 seconds to turn the earbuds off.
- 2. Holding both earbuds button for 5 seconds till red lights on to turn off earbuds.
- 3. Holding the MFB Touch Pannel on each ofearbuds for another 5 seconds till blue light turn on and off, and then clicking the MFB Touch Pannel on each of earbuds twice quickly, the reset process will be done when the Purple light on for 1s, then two earbuds flash red and blue alternately.



In case there is [Connection Unsuccessful] in your devices

please consider to delete all historical records of [TOZO-NC9 Plus] and try the paring process again.

5.0 Switch between noise-control modes

Click the left earbud to switch the Active Noise Cancellation/Transparency mode.

The Active Noise Cancellation function are not available when using single earphone.



If the electromagnetic interference signal is strong in your area,

it may affect the Bluetooth connection, and the earbuds will be silent or disconnected, please reconnect it or change the place of use.



6.0 Active Noise Cancellation Mode

With Active Noise Cancellation, an outward-facing microphone detects external sounds, which your TOZO NC9 Plus earbuds then counter with anti-noise, canceling the external sounds before you hear them. An inward-facing microphone listens inside your ear for unwanted internal sounds, which your TOZO NC9 Plus earbuds also counter with anti-noise.



Active Noise Cancellation

7.0 Transpsrency Mode

Transparency mode can enhance the voice frequency band and improve the perception of the surrounding sound, so you can hear what's going on around you with out taking off the earbuds.

Active Noise Cancellation and Transparency mode work best when your TOZO NC9 Plus fit well and wearing correctly.



8.0 Active Noise Cancellation Mode


 $\label{lem:constraint} \textbf{Active Noise Cancellation Off Mode is the default mode.}$

9.0 BOX Wireless Charging

Designed for the modern life, never be strangled by headphone cables.

Enjoy the convenience of wireless charging and free charging devices provided by airports, hotels, and café shops around the world.

(Wireless Charging Pad Not Included)



10.0 Detailed Function List 1. Manually Turn On; After the headset is in close status, tap and hold the touch control for 3 seconds and release it, the blue light will turn on. Then looking for the phone with the last connect connection memory within 10s after the headset is turned on. If it is not found, enter the pairing state (the red and blue lights flash alternately). Turn on 2. Open the charging case, they will power on automatically and will connect to each other automatically within 10 seconds. Then finding the phone with the last connect connection memory within 10s after the headset is turned on. If it is not found, enter the pairing state. 1. Manually Turn Off: Tap the Touch Control 5 seconds for turn off in not playing status, and then release it, the red light will turn off after one second. Turn off 2. Auto Turn Off: Put the earbuds in to the charging case and close the charging case, the earbuds will turn off automatically. After the two earbuds are paired for more than 15 seconds, if they are not successfully paired, Pairing Timeout they will enter the mobile phone pairing state. When the earbuds are turned off, tap and hold the touch control simultaneously for 5 econds and release them to pairing mode (the red/blue light flashes alternately), thensearching for pairing name"TOZO-NC9 Plus" and select it in your mobile phone. Phone Pairing 1. Take out the 2 headset from charging base, they will power on automatically and will connect each other automatically within 10 seconds. 2. The two earbuds flash red and blue alternately (Pairing mode) 3. Search for pairing name"TOZO-NC9 Plus" and select it in your mobile phone. Automatically Turn Off after no connection for more than 5 minutes. After the headset is disconnected from the phone at a long distance, it will Auto Turn Off automatically turn off after more than 5 minutes.(Normal mode)

	·
Restore Factory Settings	In case reset step not reslove your issue, please restore to factory setting: 1. Pick up two earbuds from charging case, then holding both earbuds button for 5 seconds till red lights on to turn off earbuds. 2. Holding the MFB Touch Pannel on each of earbuds for 5 seconds till blue light turn on and off, and then clicking the MFB Touch Pannel on each of earbuds 3 times quickly, the Restore Factory Settings process will be done when the red light. 3. Put earbuds into charging case, and then take them out to connect records of "TOZO-NC9 Plus" on your phone.
Turn on for re-connection	1. Tap the touch control for 3 seconds and release to turn on the earbuds→ wait for a few seconds for the earbuds to automatically interconnect with each other→ wait for a few seconds for the earbuds to connect with the paired phone → the connection is successful. 2. Open the charging case, they will power on automatically and will connect to each other automatically within 10 seconds→wait for a few seconds for the earbuds to connect with the paired phone → the connection is successful.
Over distance for re-connection	After the headset is disconnected from the phone at a long distance, it can automatically reconnect when it returns to the close distance with the phone within 5 minutes. More than 5 minutes, the headset will automatically turn off.
Answer Phone Call	Tap the touch control once to answer the incoming call.
Hang up Phone Call	Tap and hold the Touch Control for 2 seconds to hand up the phone.
Reject Incoming Call	Tap and hold the Touch Control for 2 seconds to reject the incoming call.
Cancel dialing	Tap and hold the Touch Control for 2 seconds to cancel dialing before dialing out and the other party fails to answer.

Play/Pause	When playing music, tap the Right touch control once to pause/play(The left headset cannot switch to play/pause).
Next Track	Double-Tap the Right Touch Control twice for backward when playing music.
Previous Track	Double-Tap the Left Touch Control twice for previous when playing music.
Volume +	Tap and hold the Touch Control on Right earbud when playing music.
Volume -	Tap and hold the Touch Control on Left earbud when playing music.
Voice interaction of Siri	In standby mode, quickly tap the Touch control 3 times to turn on voice interaction of mobile phone.
Primary / Secondary switch automatically	When listening to music, put either headset back into the charging case, and the other headset will not be affected.

11.0 Function List

11.1 Left earbud	
Turn On	Open the charging case, they will power on automatically it will turn on automatically.
	Tap the Touch Control 3 seconds for Turn On.
Turn Off	Put back the charging case will turn off & charge automatically.
	Tap the Touch Control 5 seconds for turn off in not playing status.
	Automatically Turn Off after no connection for more than 5 minutes.(Normal mode)
Previous Track	Tap the Left Touch Control twice for backward.
Volume-	Tap and hold the Touch Control on Left earbud.
Active Noise Cancellation Mode	Tap the Left Touch control Once.
Transparent mode	Tap the Left Touch control Once.
Noise-control OFF	Put the earbuds into the charging case, it will automatically switch to Noise-control OFF when you take it out.
Hang up Phone Call	Tap and hold the Touch Control for 2 seconds on Left earbud.
Reject Incoming Call	Tap and hold the Touch Control for 2 seconds on Left earbud.
Cancell Phone Call	Tap and hold the Touch Control for 2 seconds on Left earbud.

11.2 Rightearbud	
Turn On	Open the charging case, they will power on automatically it will turn on automatically.
	Tap the Touch Control 3 seconds for Turn On.
Turn Off	Put back the charging case will turn off & charge automatically.
	Tap the Touch Control 5 seconds for turn off in not playing status.
	Automatically Turn Off after no connection for more than 5 minutes.(Normal mode)
Next Track	Tap the Right Touch Control twice for backward.
Volume +	Tap and hold the Touch Control on Right earbud.
Play/Pause	Tap the Touch Control Button once on Right earbud.
Answer Phone Call	Tap the Touch Control Button once on Right earbud.
Hang up Phone Call	Tap and hold the Touch Control for 2 seconds on Right earbud.
Reject Incoming Call	Tap and hold the Touch Control for 2 seconds on Right earbud.
Cancel Phone Call	Tap and hold the Touch Control for 2 seconds on Right earbud.

SPECIAL REMINDER:

Wipe the hardware contacts of the headset and charging box when the headset is not charging.



Note

If your problem is not answered above, please contactus via email , we will respond within 24 hours.



Email: info@tozostore.com



This product has built-in lithium battery.

Do not expose the productto strong sunlight,

Do not expose the productto strong sunlight, fire or throw it into the fire to avoid explosion.