


## BE1029

IPX7 Waterproof 5.0 Wireless Earbuds




Thank you for choosing the APEKX BE1029 Wireless Earbuds.  
For any assistance, please contact our customer support team  
or email us at [support@apekxtech.com](mailto:support@apekxtech.com).


## Wear Method



- Make sure is worn for the left or right ear  
note the marking on the earbud.



- Make sure to match the right or left side, and align the  
notch on the ear hook to the earbud.



- Plug the earplug along  
the ear canal into the ear.


- Revolving earbud till the end of the  
ear hook is inserted behind the ear.

## How to pair earbuds with your phone




### Step 1

Remove the stickers.



### Step 2

Put both earbuds back into the charging case.



### Step 3

Take both earbuds out from the charging case.



### Step 4


Search and select BE 1029 .



**Note:** When the earbuds cannot connect to your phone or cannot connect back with the phone, please forget the previous Blue tooth connection in the phone and turn off the Blue tooth, and then reboot the wireless earbuds and pair with the BT device again.

# Control Function

Ⓐ



## Short Press

▶▶ x 1

◀◀ x 2

📞↕ x 1

📞 x 2

🔊+ x 3


## Press and Hold

🎤 ⌚ : 02

(i on) ⌚ : 03

(i Off) ⌚ : 04

Ⓑ



## Short Press

▶▶ x 1

▶ x 2

📞↕ x 1

📞 x 2

🔊- x 3



## Auto Power On/Off Earbuds

Function	Operation	LED Indicators
Power OFF	Put both earbuds back into the charging case, earbuds will auto power off.	Both earbuds show mint blue light. (means earbuds are charging.)
Power ON	Take both earbuds out from the charging case, earbuds will auto power on and ready for pairing.	One earbud flashes mint blue light quickly, the other earbud flashes mint blue light slowly.



Note: If the charging case is completely discharged, earbuds will not auto power on while taking them out from the charging case.

## Specification

Support type: A2DP /AVRCP/HFP/HSP

Charging case input: 5V 650mA

Frequency range: 20Hz – 20,000Hz


Transmission distance: 10-15m(barrier free)

Earbuds battery: Rechargeable Li-battery 60mAh

Charging case battery: Li-battery 800mAh

Music play time: About 3.5-5 hours

## Charge




Full charge time:1.5H

When the charging case is full of power, it can charge earbuds about 3-4 times.

### Earbuds



### Charging Case



Full charge time:1.5-2H

### Charging Case

●○○○ 1%~25%(Power)

●●○○ 25%~50%(Power)

●●●○ 50%~75%(Power)

●●●● 75%~100%(Power)




Note: Earbuds will charge automatically when the charging dock is charging.


## Signal Transmission

Waterproof for daily life(you cannot dip them into water), you can wear them on when showering, swimming, washing face, exposing in the rain, having a bath, but cannot dive.

Please note this when you are swimming(as illustrate):




Above water



Under water

Notes for signal transmission distance(as illustrate)



## Earbuds Warning!

1. Please do not place the product in an environment where the temperature is too high or too low( above 45℃ or below 0℃ ) .
2. Do not dismantle or repair the earbuds under any circumstance, if necessary, please send the product to the seller for repair.
3. After the earbuds and the charger are soaked in the water, please dry them with a soft cloth or dry by airing. (If soaking in the sea water, rinse with fresh water and then dry it). Use it after 2 hours.
4. The earbuds and the BT devices will be disconnected if the distance between them is more than 10 meters.
5. Keep the device and accessories away from children and pets.
6. Since the BT signal cannot be transmitted underwater, swimming, diving will cause the signal intermittent or disconnected.
7. Do not put the earbuds into the washing machine.

## Battery Warning!

1. The battery in the product may cause fire disaster and risk of chemical burning if mishandled.
2. You can only use specified charger for this product to charge the battery.
3. The discard of battery should obey local law, if possible please recycle it . Do not dispose it as household garbage, because it may cause explosion.
4. Users are not allowed to take out or replace battery in the product unless there is a stipulation on user manual. It is very hazardous to do this, may cause a damage to product.

