



| Original                                                                            | Replacement    | Original                                                                            | Replacement        |
|-------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------|--------------------|
|    | Power          |    | Power              |
|    | 1              |    | 1                  |
|    | 2              |    | 2                  |
|    | 3              |    | 3                  |
|    | 4              |    | 4                  |
|    | 5              |    | 5                  |
|    | 6              |    | 6                  |
|    | 7              |    | 7                  |
|    | 8              |    | 8                  |
|   | 9              |   | 9                  |
|  | Guide/List     |  | Guide / EPG / -/-- |
|  | 0/Quick Access |  | 0                  |
|  | .../AD/SAP     |  | Fav / Marker / PC  |
|  | Vol+           |  | Vol+               |
|  | CH+            |  | CH+ / Page+        |
|  | Mute           |  | Mute / Dimmer      |
|  | Vol-           |  | Vol-               |

| Original                                                                              | Replacement | Original                                                                              | Replacement                 |
|---------------------------------------------------------------------------------------|-------------|---------------------------------------------------------------------------------------|-----------------------------|
|    | CH-         |    | CH- / Page-                 |
|    | Home        |    | Menu / Home                 |
|    | Voice       |    | Display / Media             |
|    | Sources     |    | AV / Input / RDS            |
|    | Up          |    | Up                          |
|    | Left        |    | Left                        |
|    | Wheel Up    |    | >>I / Preset+               |
|    | Right       |    | Right                       |
|    | Wheel Down  |    | I<< / Preset-               |
|   | OK          |   | OK                          |
|  | Down        |  | Down                        |
|  | Back        |  | Back / Return               |
|  | *           |  | D.Menu / Top                |
|  | Red         |  | Red / Netflix / Search      |
|  | Green       |  | Green / APP / Repeat        |
|  | Yellow      |  | Yellow / YouTube / Repeat   |
|  | Blue        |  | Blue / Prime Video / Random |



