



Original	Replacement
	Input
	Mute
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	EPG
	0
	Recall
	[+]
	Menu/Exit

Original	Replacement
	Menu/Exit
	Vol+
	Up
	CH+ / Page+
	Vol-
	Left
	OK
	Right
	CH- / Page-
	Down
	FAV
	CH List
	I/II
	Sleep
	USB
	Audio
	Video





Original	Replacement
	Info / Angle
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Text / Goto
	Shift + Text /
	Zoom / Size
	Rec / Rec Mode
	Pause / Step / Freeze
	Subtitle / EQ
	Stop / Hold
	Play / Slow

Original	Replacement

