
Remo4.207 User Manual

Assembly drawing



Instructions

- 1, Connect the product according to the assembly drawing.
- 2, When powered on and enter the pairing state, accompanied by a prompt tone.
- 3, Turn on the Bluetooth function on your phone, search the Bluetooth name "Remo Audio 4", and pair it. After the pairing is successful, there will be a prompt tone.
- 4, Open the tracks on your phone, play music, and then you can perform music controls such as pause / play, volume down, volume up, previous track, next track, etc. on your phone.
- 5. Disconnect the Bluetooth connection on your phone, accompanied by a prompt tone.

Remark:

Please note that Bluetooth has a reconnection function.

Product parameters

Power Input	DC12V2A
Speaker Output	8W*2

Common troubleshooting

Fault	Possible causes and solutions
Unable to power on	 No power connection. The wire is disconnected or the plug is not fully inserted.



	3. The connected socket is faulty.
No sound	1. The extension cable of the speaker is
	disconnected, please check all the connections
	or reconnect them.
Bluetooth cannot connect	1. Already connected to other Bluetooth
	devices, power off, then power on again to
	search for Bluetooth pairing.
	2. Beyond the effective range. Please do not
	connect beyond 8M of this product. Do not try
	to connect through obstacles.
The music is played by another device	1. As Bluetooth has a back-connection function,
	please check whether the phone is paired with
	two Bluetooth devices at the same time, cancel
	the pairing of one of them, and click the play
	button on the phone.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.