

# G69 TWS earphone - ANC version

## User Manual



## Warning

Read the below warning thoroughly before you start using your headset. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to.

To reduce the risk of injury :

Keep batteries out of reach of children.

Do not heat, open, or dispose of battery pack in fire.

Do not allow metal objects to touch the battery on the device.

Do not expose battery pack to excessive heat.

## Paring

### 1: Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

### 2: Syncing your earphones..

When earphones do not sync together or enter disconnected state during use.

1): Turn off both earphones and turn back on.

2): If that does not work, placing both earphones back into case, closing the charging case and then open the charging case again.

3): While earphones is out of the charging case. Press and hold both earphones for 3 seconds. This will force the earphones to turn off and on again and sync with each other.

3: Open up Bluetooth setting on your smart device and scan for **G69--ANC**.

# Operation

## 1: Power on/off .

- 1.) Take the earphones out of the charging case, automatically turn on;  
Put the earphones back to the charging case, automatically turn off;
- 2.) Long press 3 seconds to turn on  
Long press 5 seconds to turn off.

## 2: Play/Pause music.

When listening to music.

Tap left/right earphones once to play or pause the music.

## 3: Previous /Next Song

When listening to music.

Quick double tap left earphones to go to previous song.

Quick double tap right earphones to go to next song.

## 4: Mode

When taking the earphones out of the charging case, it is regular Bluetooth mode.

Long press left or right earphones for 2 seconds to enter **Transparent mode**;

Long press left or right earphones for 2 seconds again to enter **Noise reduction mode**;

Long press left or right earphones for 2 seconds again to enter **regular Bluetooth mode**.

## 5: Answer/Hang up

When there is an incoming call.

Tap left or right earphones once to answer the call.

Tap left or right earphones again to end the call.

## 6: Reject

When there is an incoming call.

Quick double tap left or right earphones to reject the call.

## 7: Voice assistant

Quick tap left or right earphones 3 times to activate voice assistant.

# Charging Function

Fully charge the case and earphones before using for the first time.

## 1: Charging the charging case

There is a Type-C cable included in the packaging. Connect it to the Type-C charging port and the other end into a USB powered source to charge your case.

## Technical Specs:

---

ANC chipset: JL

Earphones battery capacity: 40mAh

Charging case battery capacity: 350mAh

Speaker impedance:  $32\Omega \pm 15\%$

Effective distance: 10M

Play time: Bluetooth on, ANC on: Up to 7 hours

Bluetooth on, ANC off: Up to 8 hours

Standby time: 20-22 hours

Earphones charging time: About 1H

Charging case charging time: About 1.5H

## Package Contents:

---

- 2 x headset
- 1 x User manual
- 1 x Type-C cable