


INSTRUCTION MANUAL



Model: H1

Please read this manual carefully
before using the projector.



Important Safety Considerations

Attentions:

Thank you for purchasing this series of video projectors.

Please read through this User's manual for proper use of this product.



Friendly Reminder:

- ① Do not look directly into the lens while the projector is running, as strong light may damage your eyes.
- ② Do not block the air outlet to prevent the projector from cooling down because internal electronics are damaged.
- ③ Keep the projector and accessories out of the reach of children.
- ④ Please make sure that the working environment of the projector is dry and ventilated.
- ⑤ To prevent electric shock, please keep the projector out of the rain and away from moisture, It is recommended to switch off the projector after it has run for 6 hours non-stop.
- ⑥ Do not press hard on the projector, as it may damage the product.
- ⑦ Do not throw, hit, or shake the projector to avoid damaging the circuit board.
- ⑧ Any questions after receiving the projector, please contact us, we will quickly and correctly solve your problem within 24 hours and give you a satisfactory answer.

Package contents

AV cable * 1

HDMI cable * 1


Power cord * 1

Remote control * 1

Projector screen * 1

User Manual * 1

Projector description



1. IR Receiver

2. Lens

3. IR Receiver

4. USB2 Port

5. AV Port

6. USB Port


7. Headphone Jack

8.HDMI Port

9.Cooling Window

10.Power Jack

Projector description



1. Focusing

2. Keystone Correction

3. Power Key

4. Source Key

5. Arrow Keys

6. Return Key

7. Menu Key

8. OK Key

9. Bottom Label

(Tear off the bottom sticker, you can remove the bottom dust cover to clean up the dust)

10. Hanger Fixing Screw Holes


(4 Points: Remove the machine foot pads before hoisting)

11. Hole for Stand(1/4 inch)

12. Height Adjustment Machine Feet

13. Dust-Proof Net

Remote Control Button Function



1. Power
2. Aspect Ratio
3. Arrow Keys
4. Home
5. Menu
6. Volume Down
7. Menu
8. Screen Flip
9. Source
10. Enter
11. Return
12. Volume Up
13. Mute


Specification


Model	Multimedia Projector
Lamp	LED
Image System	LCD
Language	English, total 25Languages
Resolution	1920×1080p
Input Voltage	220V~ 50Hz 1A
Weight	1.57 KG
Working Temp	0-35°C
Input Port	HDMI / USB / AV
Output Port	Headphone
Aspect Ratio	16:9 / 4:3
Size	240×210×96mm
Operation Mode	Manual / Remote Control

Multimedia Supported Formats

Image Format	JPG / PNG / BMP / JPEG
Video Format	MP4 / MKV / WMV / RMVB / RM / AVI / FLV / TRP / VOB / 3GP / DIVX / TP / TS / MPG / M2TS / F4V / DAT
Audio Format	MP3 / AAC / WAV / FLAC / WMA / M4A


Power/Focus/KeystoneCorrection

- 1: Plug the power cord into a power outlet.
- 2: Press the button “” on the projector or on the remote control.



Focus


Let the projector be perpendicular to the wall, with the Focusing button to make the picture clear. When focusing, you can broadcast programs to help you finish focus.



Keystone Correction

In different angle you put the projector, the projection will Deformation like a trapezoid, use the keystone correction to make it correctly.


Connection



Add:Different brand laptop output keys are as follows:

Lenovo	Fn+F3
Dell	Fn+F8
HP	Fn+F4
ThinkPad	Fn+F7
Asus	Fn+F8
Acer	Fn+F5
Samsung	Fn+F4
Sony	Fn+F7

Fujitsu	Fn+F10
Haier	Fn+F3
NEC	Fn+F3
Panasonic	Fn+F3
Sharp	Fn+F5
Hitachi	Fn+F7
TOSHIBA	Fn+F5

The user of windows 7 or over windows 7. Simply press the  +P, select “copy” to connect. If the operation above is invalid, Please update the computer graphics driver.

Connect the Smartphones

Note: When connecting to a smartphone, please purchase an HDMI conversion cable (for smartphones) separately. (Note: If you purchase the wrong HDMI conversion cable, you will not be able to project the screen of your smartphone normally. Please contact us for any questions.)

When connecting to iPhone / iPad

* You need extra lightning to HDMI adapter to connect your iOS device to the projector. (HDMI adapter not included)

1. Plug the HDMI plug of the HDMI conversion cable into the "HDMI" port of the projector.
 2. Insert the USB plug of the HDMI conversion cable into the USB port of the projector.
 3. Plug the lightning terminal into your iPhone / iPad.
 4. Select "HDMI" on the screen with the arrow keys on the remote control or projector.
 5. Select "Trust" on the iPhone / iPad screen and enter the passcode.
- Then you will see the iPhone / iPad screen.




Connect the Smartphones

When connecting to an Android smartphone

* You need to buy a Micro USB/ Type C to HDMI adapter to connect your Android devices.(HDMI adapter not included)

1. Plug the HDMI plug of the HDMI conversion cable into the "HDMI" port of the projector.
2. Insert the USB plug of the HDMI conversion cable into the USB port of the projector.
3. Insert the lightning terminal / Type-C terminal into your smartphone.
4. Select "HDMI" on the screen with the arrow keys on the remote control or projector. Then the smartphone screen will be displayed.




Please note:

The method of connecting the fire stick is the same.

Connecting

1. Connect a USB drive

- ① Different from other devices, when you connect a USB drive, you don't need to click “” to select the USB signal source, directly select the file you want to play on the main menu.
- ② To play a video stored in a USB drive, select "Movie" on the main menu, and press the "OK".
- ③ To play a picture, music or text stored in a USB drive, select "Photo"/"Music"/"Text" on the main menu, and press the "OK".

2. Connect AV video devices

- ① Use the 3 in 1 video cable (Included in the package) to connect with AV.
- ② Choose the media signal channel: "AV".

3. Connect 3.5mm audio devices


Support 3.5mm earphones and other cable sound devices.

Bluetooth Settings

Please note: The Bluetooth function is only compatible with audio output devices such as soundbars and Bluetooth speakers.

- 1. Click "Bluetooth".
- 2. Set Bluetooth on / off on the “ < / > ” of the projector or remote control.
- 3. Search for Bluetooth on the audio output device.
- 4. Connect the Bluetooth of the audio output device.
- 5. The Bluetooth connection is complete.

Bluetooth Settings



More Tips about Netflix, Prime video, Hulu, etc

It works with youtube, chrome, safari, facetime when you connect it to a smartphone directly.

And it doesn't support play protected video via APP when you connect it to your smartphone directly. (Netflix, Prime video, Hulu, etc) Due to these video have an encryption protocol, the projector has no right to recognized when it is connected directly to the phone via the USB interface. You can try play protected video via browser when connect to your iphone.

But it works with Netflix, Amazon prime video or any other copyright videos when connecting this projector to a laptop, fire tv stick, Roku or Chrome cast. The reason why the fire stick or other HDMI device can play Netflix is because the HDMI interface encryption protocol includes Netflix's.

Last but not least this projector does not support Dolby sound. So there will be no sound when you play Dolby sound videos, (Amazon fire stick, Netflix, Blue ray movies and so on). In this case, please kindly turn off the Dolby sound on your device or apps.

The indtruction for your reference to turn off the Dolby sound (Settings > Display & Sounds > Audio > Dolby Digital Output > and then turn Dolby Digital (OFF)

Projector Settings

Please set the option related to "Image" on this screen


Zoom settings

1. Click "Menu" on the projector or "Menu" on the remote control to move to the setting menu.
2. Click "Zoom" and set the zoom with "< / >" on the projector or remote control.



Color Temperature Setting


The "medium", "warm" and "cold" temperature modes default for different color preferences.



Projector Settings

Noise Reduction Settings

Set screen noise reduction effect (medium/high/off/low)



Please set your Voice related options on this screen

Audio: Audio Mode/Treble/Bass.



Projector Settings


Please set options related to "Settings" on this screen

1. Click "Menu" on the projector or "Menu" on the remote control to move to the settings menu.
2. Use Left and Right on the projector or remote control to move to Settings.



Language Settings


1. Set the language on your system (there are 23 languages). The initial setting is English.
2. Use " \wedge / \vee / \lt / \gt " on the projector or remote control to search for the language.



Projector Settings

Projection Mode Settings

Adjust the image upside down. You can get the desired image by clicking the "OK" key.



Reset to Default Settings

Please choose "Reset to Default", click "ok", and return to the shipping default setting.



