


Batman Bluetooth Gamepad User Manual

Instruction Manual(PG-9076)


Applicable instructions

- 1. Thanks for purchasing iPega developed Batman 3 in 1 Bluetooth GamePad.
- 2.This Gamepad support playing games on Bluetooth enabled Android tablet/ smart phone/ TV box/ smart TV/ VR, and Win7/ Win8/ Win10 PC without any drivers. Also support 2.4G wireless connection with PS3 for playing games.
- 3.LB button and RB button have simulator function, much more focus on operating details, make games controlled exactly.
- 4. Support TURBO(acceleration) function, make it stronger and faster when playing games.
- 5.Multimedia player buttons "volume +, -,"last ","next ""Play / Pause" can be used under Mouse Mode.
- ★ Due to the official game platform software upgrades or source code changes and other not resist factors caused some of the game can not be played or connected with our Gamepad, iPega company has no responsibility.iPega reserve the right of final interpretation for this.
- * iOS devices (iPhone/iPad) has authorization limited, so currently for Chinese user only.

Introduction for key functions:



Usage of Android device



- 1. Press and hold Android button + 1 button for 2 seconds at the same time, 4 LED indicator lights will blink simultaneously in a rapid manner at this moment. Refer Pic1
- 2.Open the Bluetooth on Android device, click searching, find and select "PG-9076" for Bluetooth pairing. Refer Pic2
- 3. LED1 lit on after Bluetooth connected. Refer Pic3
- 4. Then you are ready for playing games on Android devices.

Important notice for games capability in this mode:

- 1.Download simulator games from the third party Games App. Scan the QR code or input www.xiaoji001.com to your phone browser to download the Android Game Center App, there has vast of most popular available games supportable.
- 2.Download gamepad enabled games (similar console games as below) from Google Playstore which you can play directly. You can map button in the game settings for some of the game, such as ShadowGun. Recommend console game list: Implosion / Dead Trigger / Dead Effect / CS Portable / The dungeon hunter 4 glory palace / Shadowgun: DeadZone / SoulCraft Action RPG 3.If you want play some of the online games such as PUBG, Mobile lenges, Rules of survival etc which downloaded from Google Playstore, then you need download the Octopus driver for buttons mapping, check the operation guide video on PEGA HK Youtube.

Scan to download Android Game Center:



www.xiaoii001.com




Octopus Driver: http://www.phoenixos. com/octopus/intro

How to use USB data cable connect to PC for gaming:

- Hold on the START key on gamepad and connect gamepad to the computer's USB port via the USB cable.
 At this point entered the USB wired mode.
- 2. After the wired mode connected, the LED2 indicator is on; In this case, it is the PS3 mode. you can play games on Sony PS3.
- 3. Press the key for three seconds to switch to x-input mode and playing of 360 games on PC.

The LED3 indicator lights up once successful connected.



Bluetooth connection to PC:

- 1. With the gamepad off, press and hold gamepad button Android + simultaneously for searching the Bluetooth device, and the LED1-LED4 flash quickly. (If your PC has Bluetooth function, please go to step2.2)
- 2.1 Insert the Bluetooth 4.0 Dongle into the USB interface on PC device; The driver will be installed by Windows system automatically;
- 2.2 After the driver is installed successfully, the symbol of the Bluetooth device will be displayed in the lower right corner of the computer;
- 2.3 Move the mouse to the Bluetooth symbol, click the right mouse button, and select "Add device";
- 2.4 After selecting "Add device", the device model (PG-9076) icon can be searched;
- 2.5 Click "next", and select "Do not use the code to match", it will be automatically added after confirmed, then remind the Bluetooth was connected! After connected, the indicator light is always on;
- 2.6 It will be D_INPUT mode after the Bluetooth is connected successfully and can support the games running in simulator way.

Turbo Function:

- 1. Enabling of Turbo Function: First, press the key that needs the turbo function, for example, the A key and then, press the Turbo key. At this moment, the A key will be enabled with the turbo function.
- 2. Disabling of Turbo Function: First, press the key that has been set up with the turbo function, for example, the A key and then, press the Turbo key. At this moment, the turbo function in A key will be disabled.



2.4G wireless connect to PS3 /Windows PC /Android Smart TV and TV box:

- 1. Plug 2.4G Wireless dongle into the USB port of your PS3, Windows PC, Android Smart TV or TV box.
- entered wireless matching mode.
- 3. LED2 will light on once successfully connected.
- 4. Then you are ready for playing games.











Bluetooth Gamepad 2.4G Wireless dongle

PS3

Android Smart TV

Android Smart TV Box

Mouse & Multimedia Function

- 1. Multimedia player function, need to operate in mouse mode;
- 2. After successful connection in HID mode, you can switch to mouse mode by short press hey; LED2 lights up at this time;
- 3. In mouse mode:

Y key: volume +; A key: volume -; X key: previous song; B key: next song; L2 key: play/pause;


L1 key: left mouse button; R2 key: play/pause; R1 key: Right mouse button; left 3D: mouse fast moving; right 3D: mouse slow moving.

4. Short press key if you want switch back to HID made from mouse mode.

Charge/ Sleep/ Wake up function of Gamepad:

- 1. When the gamepad is power off (Press 🏠 button to power on/off) while it is charging, 4 LED indicator lights will slowly blink. When the charging is completed, the lights will be off! When the gamepad is connected to other device via Bluetooth while it is charging, the current mode light will slowly blink. When the charging is completed, the light will be on.
- 2. Sleep/Wake-Up Function: The game pad cannot be used within 10 minutes and it will enter into the sleep status. When you need to use it again, press the

 key and it will automatically return to wake-up status.
- 3. When the battery power is low, the current mode indicator light will blink rapidly.



Operation instructions:

	Android system		
Working mode	Android general mode (HID Gamepad Mode)	Mouse Mode	
Bluetooth pairing buttons (Press and hold on 2's)	Android+ 🖒 button	In HID mode, press the button to shift	
Indicator	LED1	LED2	
Remark	Press button to swift to mouse mode from Android general mode		

	Playstation 3	Windows system	
Working mode	2.4G wireless mode	Connet by USB data Cable mode	2.4G wireless mode
Bluetooth pairing buttons (Press and hold on 2's)	+ SELECT button	Press the START key to power on the PS3 mode/press for 3 seconds to enter the X-input mode	+ SELECT
Indicator	LED1	PS3 mode: LED2 X-input mode: LED3	LED2
Remark	Need to use 2.4 wireless Dongle	Need USB cable	Need to use 2.4 wireless Dongle

Electrical Parameters;

1. Working voltage: DC3.7V

2. Working current: 30 mA

3.Consecutive Usage Hours: 10H

4.Sleep mode current: : <10uA

5. Charging voltage/current: DC5V/500mA

6.Bluetooth transmission distance: ≤8M

7.Battery capacity: 380mAh

8.Standby time: up to 30days once fully charged

Notes:

- Please do not store this product in wet or high-temperature areas.
- 2. Don't knap, beat, drub, pierce, or try to decompose this product, to avoid unnecessary damage to the product.
- 3. The product has built-in batteries, and please don't discard them together with the garbages.
- 4. Don't charge the controller in a place near the fire or other heat source.
- 5. Non professional personnel should not disassemble the product, otherwise it will not be covered in the after-sales warranty service.

Frequency asked question to operate this Gamepad

Q1: I opened Bluetooth searching, but still can't pair it with my device?

A2: Please turn off and ignore the previous connected device. Then reopen Bluetooth for connect. If you still can't connect, then please use the needle press the RESET button on the back of Gamepad for 5 seconds. Then reconnect the Bluetooth.

Q2: I can't turn on the Gamepad.

A3: Please recharge the Gamepad before you use it at the first time or use it again after a long period. Please check the charge indicator light turn on while charging and will turn off once fully charged. If the Charge indicator do not light on while charge cable connected to the power source, then please try to change a charge cable or use the needle press the RESET button on the back of Gamepad for 5 seconds.

Q3: Joystick moving itself or other buttons works improper when entered the game.

A4: Please use the needle press the RESET button on the back of Gamepad for 5 seconds. Please be reminded don't touch wrong buttons while Bluetooth pairing.

Accessories List:









Gamepad x1

2.4G Wireless dongle User Manual x1

Micro USB cable x1